
AND WILL ALIFORNIA



Assembly Manual

09-0016-00



FIBERFAB INTERNATIONAL, INC. 6807 Wayzata Blvd. • Minneapolis, MN 55426

TABLE OF CONTENTS

Lower Decorative Molding - Standard Assembly Only	Hood Handle - Standard Assembly Only	: : : : : : : : : : : : : : : : : : : :					•	•		Horn Grilles And Front Turn Signals		SECTION IV BODY PREASSEMBLY	To Cut A Scribe Line	Scribe Lines	Fiberglass Preparation	Mechanical And Chassis Preparation	Brake Lines	Rear Suspension Adjustment	Lowering The Front End	Modifying The Shift Rod	Volkswagen Pan Shortening		SECTION III PAN SHORTENING		Removal Of Clutch, Brake, And Gas Pedal Assembly	Preparation Of Chassis	Removing The Volkswagen Body		SECTION II DISASSEMBLY		Hardware And Fasteners		:	Tools And Parts (Miscallangous)	Parts To Re Purchased	
Instrument Harness	ConnectionsVI-7	Main Harness-Passenger Compartment, Instrument, Fuse	Main Harness Front BranchVI-3	Main Harness Rear Branch	Main Harness Engine Branch	Wiring	Wiring Harness Installation		SECTION VI WIRING		Installing Windshield Wiper Motor	eel (Optional)		Gas Tank Installation	Gas Tank Modification	Glassing the Body	Engine Compartment Inserts	HornsV-10	Front Fender PanelsV-10		Steering Column	Bumper Or Optional Nerf Bars	Spare Tire Mount Body Support	Front Body Support	Assembling Body To Pan	Dash Studs For Optional Tonneau Cover		SECTION V BODY AND PAN ASSEMBLY		Door Lock Installation IV-20		Since Block Block			 Boll Bar (Ontional)	

TABLE OF CONTENTS

Carpet Trim	Wiper Arms And Blades VII-4 Door Panel Upholstery VII-6 Door Top Trim VII-7 Front Seat Fabrication VII-8 Rear Seat Cushion VII-11 Seat Installation VII-12 Seat Belts VII-12	SECTION VII UPHOLSTERY TRIM AND TOP Upholstery	Instrument Harness Fuse Connections
SECTION X ADDENDUMS INDEX	Nut And Bolt Kit	Mirrors	Tonneau Cover (Optional)


SECTION I INTRODUCTION - PARTS, TOOLS AND SPECIFICATIONS

PARTS TO BE PURCHASED (THESE PARTS ARE ALSO AVAILABLE FROM OUR PARTS DEPT.) IMPORTANT: Order these items early due to possible delays with your local dealer.

	Gas Tank 1961-67 VW Beetle Part No. 113201075AB (only needed if using Super Beetle. Super Beetle tank cannot be used) *Not available from our Parts Dept.	FROM LOCAL VW DEALER
	etle only needed if using s tank cannot be used) arts Dept.	Bitter State of Fried States and Fried States
STY or high shing		

MISCELLANEOUS ITEMS


Heater Hose (2 Req'd.)
Part No. 813-1313
Napa Balkampor equivalent universal emission control duct 2" x 36"



12 Volt Flasher ______2 Prong

Dimmer Switch (Floor Mounted, 12V)

FOR SUPER BEETLE CONVERSION PARTS SEE APPENDIX A



MISCELLANEOUS ITEMS

Spray cans of black paint

Sandpaper - 60, 80, 220, 400, 600 grit

Pop rivet gun

Large tube of contact cement Staple Gun

1 qt. of Rust Retardant Paint

4 sq. yards of 1½ oz. fiberglass mat or 30 ft. of 6" wide fiberglass tape Two 2" brushes (throw away bristle type)

China Marker (Grease Pencil)

Can of Penetrating Oil

Mineral Spirits 6 sq. ft. of rubber matting 20 ft. of 1/4 x 3/4" foam weather stripping

2 cans 3M "90" spray adhesive


10-24 Tap

Gallon of Polyester fiberglass resin and hardener (Methyl Ethyl Ketone)

1 quart of Acetone or any safe resin solvent for brush cleaning

2 Saw Horses 50" wide, 30" high

1-2



CONSIDERATIONS WHEN BUYING A VOLKSWAGEN

YEAR AND TYPE

This Replica assembly can be built utilizing any VW Beetle. (It can be built using a VW Super Beetle. This requires the use of our Super Beetle Conversion Kit and the purchase of additional parts. See Appendix.)

We recommend using 1969 or newer Beetles because of improved horse power and improved rear suspension.

WHERE TO FIND A VW

Local Newspaper Classified Advertisements

Neighborhood Flyers/Newspapers

SPEEDSTER SUPERIMPOSED OVER BEETLE

Bulletin Boards in Gas Stations, Supermarkets, Apartment complexes, Schools and Colleges.

Places of Work

Tell your friends and fellow workers about your project - they may help.

VW repair garages. (Some may sell complete ly reconditioned chassis and engines.)

VW Dealerships

Automobile adjusters or insurance agents

Automobile salvage yards

Used Car Dealerships

WHAT TO LOOK FOR BEFORE BUYING YOUR VW

Before you begin, purchase a VW repair manual such as - "VW Official Service Manual" published by Robert Bentley Inc. This will help you identify the parts which you will want to check. Remember that Beetles with damaged bodies and interiors can be used to assemble your kit. As a matter of fact a damaged car is ideal if the floor pan is not bent.

☐ Inspect the Pan

Check for severe rust or damages caused by collision or battery acid. (Small holes in the floor pan can be patched using fiberglass.)

☐ Check the Wheel Base

☐ Use the usual troubleshooting methods.	Check the Engine:	positive shifting.	noisy - check for smooth, quiet, and	Light line gear box differential should not be	-110	☐ Check the Transaxle:		chassis.)	the VW body is removed from the		cylinders. (Wheel cylinders and the		The start particular mesons and parallely	adjustment.)	(Excessive play can be corrected by	excessive	•	Check the steering and the brakes.		placed.)	snock absorbers which are easily re-	the shocks. (Most cars will need new	*ho shock (Mart Wheels, also check	sion chart the front wheels also shall	look for best parts sound by sell:	Inspect the Front End.	Nic is illistalled, see Appendix.		done offer the Super Booth control be	Suit a competent VW shop.) If a Super	the chassis requires straightening con-	or the front axles may be damaged. (If	If it is not, the chassis may be bent	both sides of the	of the front wheels to center of rear wheels. This measurement should be	☐ Measure the wheel base from the center
1962 Chassis No's 4010995 through 4846835.	from 36 HP to 40 HP.	ed in addition to an increase	the font suspension were add-	anti-sway bars, a king pin on	proved (stronger synchromesh)	4040995. Transmission was im-	1961 Chassis No's 3192507 through		(and earlier) 4 speed non-synchro gear box.	1960 Sedans are 36 HP and employ		Beetle, the following brief history is provided:	changes made through the years to the VW	To acquaint you with the manufacturing		taining the chassis and engine number.	was manufactured may be established by ob-	When shopping for a Beetle, the year the car		Beetle chassis.	tion necessary to familiarize you with the VW	The following text will provide basic informa-	1	1901 and they turn out just tine.	1061 and the transfer of VW S as old as		We prefer 1969 or newer VW's due to the		axle damage has occurred.	acceptable, assuming no engine, pan or	A VW that has been rolled-over would be		e. Oil Leaks and Compr	Check the Oil Pressure Exhaust	Repair Manual.)	(These should be listed in your VW
900	1060					1968					1967						1966												NOTE:		1965			1964		1963
chassis No. 119000001 through 1191093704. Double jointed rear axles introduced.	Charles 140000000	rear shock arrangement.	er height, modified front and	shift, introduced raised bump-	1811016098. Automatic stick	Chassis No. 118000001 through		Dual brake system.	creased HP from 50 to 53.	1177844892 12 volt system. In-	Chassis No. 117000001 through		suspension.	to a ball joint on the front	50	1161021298, HP increased	Chassis No. 116000001 through		serial number.	to 7 digits are the chassis	would indicate 1972. The last 6	5 would indicate 1965 and 2	last digit of the year, e.g.:	Ghia (4). The third digit is the	a Beetle (11), or a Karmann	two digits identify the model as	the chassis number. The first	orated the year and model in	Beginning in 1965, VW incorp-		Chassis No. 11500001	0000000	6502339	Chassis No's 5677110 through	5677118.	Chasis No's 4846836 through

1971 Chassis No. 1312000001 1972 Chassis No. 1320000001 1973 Chassis No. 1332000001 1974 Chassis No. 1342000001 1975 Chassis No. 1352000001 1976 None In summary, the 1967, 1968, 1969 sedans are 1500 cc, 53 HP, have ball-joint front ends and a 12 volt system (earlier ones are 6 volt). 1967 was the last year to have a wide	through creased 01. HP to 60.	Chassis No. 110000011 through 1103096945. HP increased from 53 to 57. Chassis No. 1112000001. HP increased from 57 to 60. Super Beetle introduced. Chassis No. 1122000001 Chassis No. 1132000001 Chassis No. 1152000001	1970 1971 1972 1973 1974 1975
--	-------------------------------	---	--

production: are provided for the five years they were in The following Super Beetle chassis numbers

> emission equipment. and later have decreased HP ratings due to 60 HP), with dual-port heads. Engines 1973 57 HP), with single-port heads. The 1971 through 1975 engines are 1600cc (rated

MAJOR ITEMS ARE INTACT, THE WRECK suspension and engine. (Refer to Fig. 1) REMEMBER, AS LONG AS THE FOUR units; floorpan, front suspension with steering MANGLED BODY FOOL YOU components, trans-axle complete with rear you need consists of the following 4 major IS USABLE. DO NOT LET A RUSTED OR When looking for a chassis, remember, what

BEFORE STARTING

standard components. of the operations covered deal with optional phases of construction of your Replica. Some items. Consult your brochure for details on NOTE: This assembly manual deals with all

through before starting work. Be sure to read this manual all the way

height. The 1970 engines are 1600cc (rated was introduced along with a raised bumper U-joint type independent rear suspension sedans, a redesigned trans-axle with a double

WHEELS AND TIRES

wheels can then be installed. fiberglassing has been done. New tires and until the body is installed on the pan and all a late model space saver spare tire T125/70 ment The best alternative here is to obtain Original VW tires should be left on the car D 15 and mount it on a 4 1/2" VW wheel. with the fenders. In addition a standard ed rolling resistance. Other tires can be used distinct handling advantage as well as decreas-VW tire will not fit in the luggage compartbut problems may develop regarding clearance have found that radial tires give the car a decreased weight of the fiberglass body we are available from our factory. With the 225/50 VR 15 in the rear. Special wheels wheel with 205/50 VR 15 tires in front and assembly is designed to use a 7" wide 15" are available from our factory. The custom Special chrome plated wheels and hub caps standard VW wheels with 165 SR15 tires. The standard assembly is designed to use

WORKING SPACE

You need a working space approximately the size of a two-car garage. The assembled chassis measures 150 x 60 inches wide. The fiberglass body occupies approximately the same space. During initial construction you will need room for both the chassis and the body until both are finished. Once the fiberglass body is mated to the chassis, only half the original space is required.

Be sure to allow sufficient space for walking storage of parts, and access to the car.

UNPACKING

Your Replica assembly is shipped in one or more crates and number of cardboard cartons. The total number of items in the shipment is indicated on the shipping documents. Since you may have ordered options, the number of items in your shipment may differ from other customers. Be sure to sign the bill of lading noting any observable damage.

Carefully check each container for evidence of damage to container or contents. If you find damage, immediately call the shipper's local office and follow shipper's instructions for submitting a claim.

HARDWARE AND FASTENERS

When disassembling your VW be sure to save all hardware. Some of this hardware will be reused when assembling the kit. Take special care to keep nuts, bolts and washers in the proper order.

WARNING

NOTE: Check factory service manual for torque specifications when reassembling removed hardware.

Structural bolts and nuts should only be replaced with equivalent parts. Replacement parts must be of equal or better strength as indicated by standard bolt and nut markings (radial lines on bolt head, raised dots on nuts.)

There are a number of choices available to you for wiring your assembly. First you can purchase our optional wiring harness which is specifically designed to accommodate our custom gauges as well as all other accessories. This is a real timesaver. Another method is to fabricate or modify your own harness based on VW wiring diagrams.

WELDING

There is some welding required in building your assembly. We suggest that you do all the welding at one time. The work can usually be accomplished in 1/2 day and most towns have mobile welders that will come to your garage and do the welding. Unless you are an experienced welder we suggest you have a professional do the work. In the long run the cost will be less. The following can be welded:

The pan cut and shortened Front end lowered Cables shortened Shift tube shortened

BEFORE STARTING

NOTE: This assembly manual deals with all phases of construction of your Replica. Some of the operations covered deal with optional items. Consult your brochure for details on standard components.

Be sure to read this manual all the way through before starting work.

Total Control of the	 □ Do use adequate ventilation when using chemicals, spraying paint, fiberglassing. Wear a mask over mouth and nose when 	habits. Take every possible precaution. Follow these basic Do's and Don'ts.	
Don't leave tools where some one can trip over them.	☐ Do pay attention to warning labels.	USE COMMON SENSE. Develop safe work	
flame.	☐ Do read all instructions.	SAFETY	
☐ Don't use air conditioning refrigerant (R-12) in the presence of an open	grinding, drilling, sawing, painting, glassing, or when handling the battery.	with each assembly kit.	
ing.	Do wear safety glasses or goggles when	it car.	
☐ Don't attempt to service air conditioning unit without proper tools or training.	and flammable liquids. Put away and out of reach of children when not in use.	requirements are. Obtain a Bill of Sale and title when you purchase your	
proper ventilation.	☐ Do use approved containers for gasoline	car. Contact your State Department of	
☐ Don't run an engine in a garage without	an your work a	☐ Keep records and receipts. You will need	
battery.	Do clean and maintain your tools	assembling the KIT.	
☐ Don't smoke when working around the	☐ Do use the proper tools.	This can help you later when you are	
chemicals.	disassembly.	Make sketches or take Polaroid photos of any assemblies that seem complicated	
pen flame heat	from the component car before starting	Doris, and washers.	
J		holts and washers	
gasoline or other flammable chemicals.	ú	to have a variety of small containers to	
	☐ Do disconnect the battery (negative) cable whenever working on electrical f	attaching hardware, wires, fuel lines, clips, etc. It would also be a good idea	
DONTS	,	Have masking tape ready to label parts,	
ents.	☐ Do keep a first aid kit in your work area.	separately, they will cost a lot more.	
Do wear proper clothing and shoes. Remove ties, jewelry and other items that can get caught in moving compon-	□ Do keep a fire extinguisher in your work area.	Save all parts and hardware, that you remove. If you try to buy all the pieces	
a good condition.	 Do use safety stands to support vehicles. Jacks are for lifting only. 	Be sure your work space is large enough.	
Do use electrical extension cords of the	DO'S	Have all the tools you need before you start.	

necessary.

the state of the s

REMOVING THE VW BODY

Removing the body from your VW is very easy. For this operation you will need a metric socket and wrench set.

NOTE: Save all nuts, bolts and washers removed during the body disassembly process.

Because of slight differences between VW model years, the exact location of parts to be removed may vary slightly. (Refer to Figure 1 for general orientation.)

- Open the trunk and remove the cardboard gas tank covering.
- Disconnect the wire to the fuel sender unit.
- Remove the pipe and 2 hoses that connect the fuel tank to the fitting that comes out of the frame. Save these pieces. Remove filler neck assembly from right side of body and save. (Cut the entire fuel filler pocket from the body, if necessary.)

NOTE: With a 1961 to 1967 tank, you will need to remove the breather pipe. On 1968 and newer tanks, you must remove the large clamp from the breather pipe boot, then remove the boot and pipe. This arrangement will vary from year to year.






Figure 1

- ☐ Remove the 4 bolts holding down the tank and lift it out.
- Under where the fuel tank was previously, you will find 2 bolts that are located 6" from the center line. Remove them. (In a Super Beetle these 2 bolts are about 2 1/4" apart on the tunnel. Save these for use with the Super Beetle conversion unit.)
- Remove the bolt from the coupling sleeve that attaches the steering column to the coupling disc.
- Remove the two bolts holding the steering column to the underside of the dash board. Pry off the retainer at the top of the collapsible section of the steering

- column and pull the column out of the car. Save the entire steering assembly.
- Disconnect the speedometer cable and save it.
- Remove and save the brake fluid reservoir.
- Disconnect the wires going to the voltage regulator.
- NOTE: The voltage regulator on later models is mounted inside the car body, behind the driver's door and under the rear seat. Be sure to save it and the wires that connect it to the generator or alternator. Earlier ones are mounted on



<u>=</u> د



			כ						l lia	; ,	the
Remove the next 2 bolts about 15" from the center.	Remove the 2 bolts about 8" out from the center of the hump.	are 6 bolts which must be removed.	on the rear seat kick poard and discard.	Remove the rubber heater outlet rings		Take out the rear seat.	into the car.	Cut the wire that goes from the coil	masmuch as you may want to use them later.	It is advisable to save all undamaged parts,	the generator which is located on the engine.
)		
	bolts from each side of the car.	there is a row of 9 bolts, plus 2 more, just forward of them. Remove these 11	Underneath the car, about 6 1/2" in	rear fender well.	Remove the 2 bolts on each side of the	The second secon	wheels. (Use Jack stands under the rear torsion tube.)	Jack up the chassis and remove the rear	models do not have these.	and closer to the body sides. Later	The last 2 bolts are slightly forward
)						
		component parts, for future use in the construction of your Replica assembly.	chassis. You should now store the	With the assistance of three or four		body off more difficult.)	removed but they will make lifting the	out of the car. (On some models the	be slid the rest of the way forward and	ing the seats fully forward and discon-	NOTE: Remove the front seats by slid-

PREPARATION OF CHASSIS

- Remove all unwanted material from the floor, such as tar and insulation.
- If the seats have not already been removed, do it now.
- at a later time. on the engine, and is left intact. The pan original VW heater/defroster valve flap patched with fiberglass or equivalent may suffer a few holes which can be brake) is attached to the heater boxes which was removed with the body. The cable guide tubes control only the main heater on/off control cable (the from the heater cable on the pan. These tracks, lever on right side of the emergency jacking points and guide tubes (if any Using a hand chisel, remove the seat battery hold down points

REMOVAL OF THE CLUTCH, BRAKE, AND GAS PEDAL ASSEMBLY

(Refer to Figure 4)

This assembly is secured to the left side of the tunnel wall.

- Disconnect the fuel and clutch cables at the motor end.
- ☐ Take out the 2 mounting bolts and the clutch, brake and gas pedal assembly will come out as one complete unit. (See Figure 4A)
- Remove the pedal stop and save it for future use.




Figure 4

<u>-</u>5


planners laken see by select chapter with come and see the second line that see the second line that see the second seed to the

SECTION III PAN SHORTENING

VW PAN SHORTENING

4				of car.	
		back 56 1/2" from front lip of pan (58 3/16" for Super Beetle) and mark		move front access plate. Remove shifter and slide shift rod out through front	
		Along bottom of tunnel, measure		nect shift rod from transmission. Re-	
		Turn chassis on its side.		Put transmission in neutral. Remove rear	
vious cuts. Section should drop out.		prevent fires.		ed.	
Finish cutting through edges of pan. Cut along tunnel, in between the two pre-		side) and pull out from housings. Blow out gas line with compressed air to		and a $5/16 \times 2 1/4$ " bolt in the other. Secure with a nut. Set aside until need-	
Gently turn chassis right side up.		At engine side cut ends off heater cables. Disconnect at heater control (right		Insert a $1/2 \times 2 \cdot 1/4$ " bolt in one end	
])	is critical.	
as not to cut into any cable housings.		back of chassis.		58 1/2" between holes. This dimension	
Be careful when cutting into tunnel, so		emergency brake cable and pull out from		from each end. This will give you	
the way to the outside edges of the pan.		At emergency brake handle, cut ends off		the other end. The hole should be 3/4"	
tom of pan and tunnel. Do not cut all				1/2" hole in one end and a 5/16" hole in	
Using a cutting torch, cut through bot-		side. Remove main brake line.		Along the center of the 2 x 4, drill a	
		ator cables and pull out from pedal		Obtain 2 lengths of 2×4 , $60''$ long.	
lines should coincide with diagram		engine cut ends off clutch and acceler-	С	all overlap of 1.01 illules.	*
additional 10", and mark. Connect all		Domous model commbly from tunnel At		the pan is then pulled together with	
2 1/2" and mark. Measure forward an		on car.		following the instructions in this section.	
body, mount hole, measure forward		transmission and leave wheels and axles		10" section is removed from the pan	
At rear corners just in front of the rear		NOTE: Disconnect universal joint at		VW pan 11.81 inches. To do this a	
lines across tunnel.		from chassis.		NOTE: It is a second of the se]
10" and mark tunnel. Draw 2 straight		car, remove engine and transmission		two fixtures should be constructed as follows:	TWE
tunnel. Measure back an additional		Using a VW service manual for your year		In order to accurately shorten the VW chassis	3

111-2



- On the top of the tunnel, measure off a 15 x 3 1/2" rectangle, starting above the front edge of the cut out. Extend a line down the side of the tunnel to meet cut out. NOTE: On some VW Beetle chassis the emergency brake is located further rearward than with others. If the rear of the emergency brake is behind the front cut, start rectangle on top 1" behind emergency brake mount.
- On the sides of the tunnel, measure 4" forward from back edge of cut out, then 4" up and 4" back. From that point extend line up to meet top rectangle. Finished lines should coincide with diagram. NOTE: Sections to be removed. (Refer to Figure 3A)
- J Place supports under chassis on each side of cutting area. Using the cutting torch, cut out rectangle on top of tunnel, being careful not to cut into any cable housings. Save cut out section.
- Make additional cuts, cutting out side sections of tunnel. Be careful not to cut any cable housings. Cut a 1/2 x 3" notch along tunnel of front section.
- All cable housing should now be exposed to view.
- At rear access cover, cut clutch and accelerator cable housings loose at weld.
- Cut emergency brake housings 1" behind opening. Bend rear part of housings up and out of the way. (Do the same thing





Figure 2



side.) for the heater controls for the right

The heater controls on the left side are

housing will be fed out the back as the both ends. not used and should be cut off flush at Gas line, clutch housing and accelerator

two sections are pushed together.

- aid in fitting together. Also bend the bottom of the tunnel of the front sec-Bend the two 4 x 4" sections outward to tion downward to give you more room.
- a pair of pliers to bend the pan as Kink. line is pulled out as you go or it will necessary. Make certain that the gas Push the two sections together, watching for areas where it might get caught. Use
- until a measurement of 58 1/2" is obtained from the outermost of the two previously to check this measurement. forward mounting hole on the rear shock holes on the front of the chassis to the Continue to fit the chassis together tower. Use the two fixtures constructed the chassis together at the outer corners. With the two fixtures in place, clamp
- not sit properly. too high it will hit the engine cover. on the same plane. If the rear end is up If too low, the body and sub frame will Adjust the two sections until they are

Spot weld the sides of the tunnel. Make sure all measurements are correct and weld tunnel all around. Use a hammer as necessary to band the metal together. Weld along the top of the pan. In the rear corners, bring the rear section down where it protrudes upwards and weld to pan. Turn chassis over and weld bottom of chassis. Return chassis to upright position.

Bend heater cable and emergency brake cable housings down to meet forward section. Cut even with front pieces. Use hack saw. Remove all burrs from inside of tubes with a file. Spot weld together. It will be necessary to bend and shift the tubes around in order to get them to line up.

Cut clutch and accelerator tubes 1" behind end of chassis and spot weld in place.

Grease and reinstall all cables back into housings. Reattach pedal assembly to tunnel using original bolts.

☐ Reinstall engine and transmission.

Obtain a VW cable shortening kit, available from our factory or any VW parts outlet. This includes new ends for the clutch, accelerator and emergency brake cables. The heater cables all function fine without new ends. Install as per instructions and attach the engine and emergency brake handle. Check for free movement of all cables.





Figure 4

E -6



MODIFYING THE SHIFT ROD

as a support and weld back together, keeping the scribed lines aligned. of the rod conforming to measurement shift rod. Cut a section out of the middle fitting pipe into the shift rod to act just obtained. Insert a piece of tight Scribe a line down the length of the hole that connects the rod to the yoke. made on the rod to the center of the rear two methods available in shortening this in shift rod coupling yoke. There are mark the shift rod directly over holes rod over hole in tunnel. At the back the tunnel, centering socket of the shift Lay shift rod on top or on the side of , one is to measure from the mark

Another method requiring no welding is also available. Once the rod is marked, drill a 3/8" hole at the marked location, keeping it in line with the existing hole. Measure 1/4" behind hole and cut rod. You may have to slightly flatten rod at the drilled point to allow it to mate with the transmission.

Reinstall shift rod and shifter. Check for free shifting. Adjust as necessary as per instructions in your VW service manual.

Once you are sure everything is functioning properly, fashion a cover for the top of the tunnel from the 15 x 3 1/2" piece of tunnel saved earlier and weld in place.




Figure 7

LOWERING FRONT END

Because of the decreased weight of the fiberglass body and the general weight shift toward the rear, the front suspension must be eased to allow the car to sit lower.

stands. Remove torsion tube assembly by removing 4 mounting bolts located on the front of the assembly.

Disconnect the steering damper at the tie rod and swing it up and out of the

Jack up chassis and support pan on jack

- way.

 Measure 2" out on each side of the an-
- Measure 2" out on each side of the anchor nut on the top torsion tube. Draw a line completely around the casing at this point. Using a tubing cutter or hack saw, cut through the upper torsion tube casing only. Do not cut through the torsion bar, just the casing. Reinstall assembly on car. If your car is a "66 or later the center anchor nut must be rotated down 45 degrees from the original position. This will put the anchor nut directly on the bottom of the tube casing.
- This is easily accomplished if you have 1 or 2 people stand on the front of the chassis. A pipe wrench fitted around the cut section is useful at this point for precise adjustment. Spot weld the cut section back in place in a number of places. Remove torsion bar assembly and completely weld casing back together. Reinstall assembly. For '65 or older

= -00

cars the anchor nut must be rotated 45 degrees downward from the original position. This will put the anchor nut directly on the front of the tube casing. Proceed as above.

NOTE: For the custom version you can lower the front an additional 5-10° for a lower stance.

REAR SUSPENSION ADJUSTMENT

J You may want to lower the rear of the car if you are building the custom model. If you wish to lower or raise the VW rear suspension consult your VW service manual for detailed instructions.

BRAKE LINES

J Remount the pedal assembly. You can use the old brake lines, however, we

suggest you renew all lines. These are available from any VW dealer. NOTE: the brake line from the master cylinder to the rear will be a little too long now that the chassis has been shortened. Simply coil the excess line forward of the master cylinder, being careful not to pinch the line.

MECHANICAL AND CHASSIS PREPARA-TION

Attention should be given to any mechanical work indicated as the chassis is easy to work on with the body removed. Regular VW mechanical service should be done, for instance: engine reconditioning, tuning and performance modifications, paint and detailing with chrome extras, lubrication and grease job. You are now just about ready to

mount your body, but before you do, we suggest that you paint the chassis.

First you must clean the chassis using either mineral spirits or lacquer thinner. The really bad areas should be cleaned with a rotary wire brush in your drill.

We suggest that the entire chassis be painted with a good quality paint such as Rustoleum. When you are completely finished painting the chassis, we recommend you buy a spray can of undercoater and cover the entire bottom pan on the surface that would be exposed to the highway salt and water.

FIBERGLASS PREPARATION

The following information will help you in working with fiberglass.

When drilling fiberglass always use the slowest speed possible. Use light pressure to avoid unnecessary heat build-

up, and ensure that the bit has started in order to prevent it from "walking".

When cutting fiberglass, always mark the outline of the cut with a grease pencil (do not use marker pencils since they can stain and discolor the lighter body colors), cut inside the drawn area, and finish off with a file. An ordinary hacksaw (or sabresaw) is sufficient, but be sure that only a metal type (fine tooth) blade is used to avoid rough cutting.

When using a sabresaw to cut fiberglass use duct tape or masking tape along cut edges and under shoe on saw(flat portion) that may come into contact with body. This will give you smoother edges and prevent chips and scratches to gel coat.

When there is no edge (inside cuts) drill hole through fiberglass large enough to accommodate saw blade.

When bolting fiberglass to metal or fiberglass to fiberglass always use a flat washer next to the fiberglass to spread the stress over a larger area.

Set up all the parts to be glassed in the correct positions, and then cut the matting (fiberglass) material to size and shape.

When cutting fiberglass along the prescribed lines, apply masking tape along the edge of the side to be kept. Cut outside the tape and finish off with a file. Remove the tape.

Have fiberglass mat or tape on hand and a gallon of resin and hardener (methylethyl keytone).

Mix the resin and the hardener according to the manufacturer's instructions.

WARNING: Be sure to observe manufacturer's safety precautions for handling the resin and the hardener.

Resin can best be applied with a brush. First apply resin in the work area, then lay in glass cloth. Thoroughly saturate the cloth with resin using the brush.

NOTE: It is essential that, when applying new fiberglass to fiberglass or metal, the matting surfaces be prepared by sanding with a medium grit sandpaper to roughen the surfaces for a better bond. Carefully sand all smooth gel coat (colored) areas to ensure a good bond. Just sand enough to give a rough surface. It is not necessary to go down to the fiberglass.

Clean the brushes or any other tools which you may have used with acetone that you can buy where you purchased the rest of your fiberglassing materials.

All finished edges of fiberglass parts, such as fender edges, should be given a light sanding. Sand only along the edge. Never sand across the edge from the inside out as this will chip the gel coat.

For minor repairs to fiberglass or gel coat see Appendix.

SCRIBE LINES

In order to insure a precision fit of the fiberglass parts in the assembly, scribe lines and drill points have been integrated into the molds. Careful attention to cutting these parts will result in a more precise fit and ease of assembly. NOTE: Scribe lines should be used as guides. Always cut inside of the line and fit part(s) by trimming where necessary.

TO CUT A SCRIBE LINE

I Run tape along the line on the good side of the scribe. Cut along the line keeping 1/8 - 1/6" from the tape. File to the tape, being careful not to over file. Finish off with a sanding block and fine sand paper.

Sand all exposed edges with a fine grit sand paper. Avoid sanding directly on gel coat surface.

HORN GRILLES AND FRONT TURN SIGNALS

- Line up horn grilles against the scribed locations below the headlights. Drill holes for studs attached to the grilles. Check scribe mark against grille.
- Drill a hole inside the scribed area as a starting point and carefully cut out area with a sabre saw with a fine blade. Mask outside of scribe mark to prevent flat of saw from scratching body.
- Remove rubber gaskets from turn signals and place against recess in horn grille. Mark where lip contacts horn grille. Cut away this area. Place gaskets back on turn signal.
- Mount horn grilles into position on body with hardware provided.
- Using the center mounting holes as a reference, cut a 3/4" hole through the body for the socket on the turn signal light.
- Remove lens and chrome bezel from turn signals and line up against the horn grilles with set screws for the chrome ring on the sides. Drill two 5/32 holes for each light through rubber gasket and body. Attach the body with hardware provided and reattach lens and chrome bezel.





Figure 1



TAILLIGHTS

- Carefully remove one of the rubber gaskets from a taillight.
- Using the scribe lines on the body as a reference place rubber taillight gasket against the body and mark exact hole location on the inside of the rubber gasket.
- NOTE: Because of the angle on the back of the light, it is necessary to remove slightly more (1/4") of material above the top scribe line and slightly less at the bottom. About 1/4" is correct. The ears scribed on the body should not be cut.
- ☐ Drill a starting hole inside the scribed area and cut out area with a sabre saw using a fine toothed blade. Mark the mounting hole locations through the rubber gasket and drill three 7/32" hole for each light.
- Insert studs on light through holes in rubber gasket and body. Secure with nuts provided. Use No. 10 flat washers and lock washers behind the nuts.

BACK UP LIGHTS

- Draw a straight line from the center of the engine compartment opening to the bottom lip of the body at the rear of the car. Use a grease pencil.
- Measure down line from lower outer lip of body at engine compartment 10 1/2" for standard assembly, 12 1/4" for custom and mark. Measure down 2 1/4" from this mark and place another mark.
- Center license plate bracket on upper mark, drill two 5/16 inch holes on 2 inch centers and secure license plate bracket to the body with 5/16" x 1" hex head cap screws with flat washer, lock washer and nuts.
- U Center rubber gasket from license backup light, along lower mark under license
 plate bracket. Drill a 1 1/2" hole in
 the center with an appropriate hole saw.
 Drill two 7/8" holes on 8" centers
 for side lights. Drill two 7/32" holes on
 5 1/2" centers for mounting studs. See
 Figure 3.
- Slide studs through gasket and body and secure with nuts provided. Use No. 10 flat washers and lock washers behind nuts.




Figure 3




Figure 4

HEADLIGHTS

- Unpack headlight assemblies and install T67 single filament 12 V parking bulbs and sealed beam. Secure with wire retainer clips packed with assemblies.
- Drill 1/2" hole through fiberglass at the bottom rear of each headlight housing on the body to accomodate the head light wires.

 Test fit headlight assemblies into housings. Grind or file edges slightly if

necessary, for proper fit.

- The rim retaining clip mounts to the inner top of each headlight housing with the lip protruding upward 1/8" away from body above the housing. Enlarge existing holes to 3/16" and drill an extra hole in each clip. Secure to headlight housing with 3/16 x 3/4" poprivets or with No. 10 x 1/2" round or pan head self-tapping screws.
- Hook headlight rim over clip and mark hole location for mounting flange on the body below the headlight. Drill 1/4" hole and secure to body with 1/4 x 1 1/2" carriage bolt, flat washer, lock washer and nut. Install plastic spacer between headlight rim and body.

IV-4

ENGINE COVER (REAR DECK)

J With a sabre saw cut out recessed area of rear deck lid where the grille fits. Be careful to cut only the outside surface. Do not cut inside surface. Paint all visable unfinished inner surfaces, with black paint for a finished appearance.

Grind or file inner lip of body at trunk recess to approximately 3/4". Apply 1/4 to 3/4" foam weather strip material to lip to seal against deck lid and prevent water from entering the engine compartment.

Take the two metal deck hinges and drill a 3/8" hole through the hook portion of each hinge. Center of hole is 1/2" from top edge of hinge. Drill two 1/4" holes in the angle portion of each hinge. The front hole is 2" back on angle closest to hole previously drilled. Rear hole is 5" back.

Place hinges on mounting surface on inside of rear deck lid. The open portion of the angles face the outside of the car at the very edge of inside center of the deck lid. Allow edge of angle to extend 1/2" beyond edge of mounting surface. Mark hole locations on deck and drill 1/4" holes. Secure hinge to deck lid with 1/4 x 1" hex head bolts, flat washer, lock washer and nuts.





Figure 5



Take the two metal hinge mounting brackets and drill two 3/8" holes through the flat mounting portion of each bracket. The holes are 1" in from the top and bottom edge. The hinge brackets are attached to the firewall with the higher portion on top.

- Place deck lid on body and center all around. Have a helper press down firmly on lid so it is flush with the body. From underneath the body position the hinge mounting brackets against the firewall. The metal ear of hinge with 3/8" hole should be on the inside of each bracket. Mark correct location on firewall. Remove deck lid and drill 3/8" holes through firewall. Mount brackets with 3/8" x 1" hex head bolts, flat washer, lock washer and nuts.
- NOTE: Place flat washer under bolt heads going through metal brackets.
- Place trunk cover back in recess, centered, and have helper press down so it is flush with the body. From inside of the trunk drill 3/8" holes through plastic brackets in line with holes in metal hinges. Fasten hinges to brackets with 3/8 x 1 1/2" hex head bolt with flat washers on each side and lock nuts. Make sure lid opens and closes correctly. Adjust, if necessary.

- Center lock pin at bottom inner most edge of deck lid 1/4" from innermost edge. Drill 5/16" hole through lip extending into area behind grille. Secure threaded portion of stud to lid with lock nuts and flat washers on each side.
- With a 2" hole saw cut hole through inside flange of lock mount support 3/4" below mounting surface. Place lock on pin with lever facing front of car and spring on lock on passenger side. Close deck lid and have helper press down so lid is flush with body. From underneath mark hole locations on
 - mounting flange. If necessary you can use washers between lock and flange to gain room. Open lid and drill two 3/8" holes through flange. Secure lock to flange with 3/8 x 1 1/2" hex head bolts, flat washers on each side, lock washer and nuts.
- Open hood to full open position and drill a 3/16" hole through left hinge and bracket for support pin. Mount pin retainer to the firewall on the left side of the hinge bracket on the driver's side. Drill a 3/16" hole through the firewall and secure with No. 10 x 1 1/2"

- machine screw with flat washer, lock washer and nut.
- Attach trunk release cable to the lever on lock. Either twist to secure or use a throttle cable stop available at most auto supply stores.
- Place grille into place and drill two 1/8" holes in each end between slats in grille. Secure to fiberglass with No. 6 x 3/4" round head stainless steel self-tapping screws.




Figure 7

IV-7




Figure 8

MENT COVER (LUGGAGE COMPART-

- Apply 1/4 x 3/4" foam weather stripping to lip of body in recess where hood fits.
- Place upper lock assembly into lower lock mechanism with release lever at the front passenger side of car. Place hood in position with front slightly elevated and mark stud with some paint or a grease pencil. Allow hood to rest on top of stud so it is marked. Drill 5/16" hole in underside of hood for stud. Place lock into position and drill two 5/16" holes in fiberglass through mounting holes.
- Use an electric drill with a rotary rasp and cut an access slot 1×5 " through inside lip in hood behind lock. Attach lock to hood with $5/16 \times 1$ " carriage head bolts, flat washer, lock washer and nuts.
- Mark smooth oval areas with 2 holes at the sides of the back of the luggage compartment with a grease pencil. Cut out with a sabre saw.
- Drill two 5/16" holes through the sides of each metal hinge 2" in from each edge. Drill another hole 5/16" through each hinge. Center hole 1/2" from upper most edge of mount hook.

IV-8

- Place hinges against outside edge of metal flanges on hood. Line edge at rear of hinge where it starts to curve with inside bottom edge of fiberglass elevation behind the metal flange. The front of hinge rests on the fiberglass at the front of flange. The rear bottom edge of hinge should be 1/2" from fiberglass at rear of flange. Drill two 5/16" holes through each hinge and flange. Secure hinges to flange with 5/16 x 1" hex head bolts, flat washers, lock washers and nuts. (Figure 9)
- drilled in hinge and hole locations on hinges to bracket with 5/16 x 1" hex frame member. Replace hood and secure drill 5/16" hole through supports where each hinge. Have a helper press down on support braces in position on top of the hinge mounts. Drill 5/16" holes through frame member. Remove supports and hole locations on supports through holes hood so it is flush all around. Mark front cross member to the outside of front. Temporarily clamp metal hood tween the rear lip and body than at the through cut out areas. Center hood in Place hood on car with hinges extending recess leaving slightly more room be-

head bolts with flat washer on both sides and lock nut. Secure hood hinge brackets to frame with 5/16 x 2 1/2" hex head bolts with flat washer, lock washer and nuts. Check for free movement and clearance in the open and closed position. Adjust, if necessary.

Cut slots in plastic support cover boxes. Trim or grind front as necessary. Set aside, as these will be fiberglassed into position later.




Figure 9

Figure 10

IV-10

BATTERY COMPARTMENT

Mark rear wall of battery compartment 4" from each side and 2" from the top. Also mark floor at forward front corners. Drill 3/4" holes where marked. The front holes are for drainage; the rear holes accommodate the battery cables. Finish holes with rubber grommets or small diameter hose slit lengthwise.

Place battery in compartment. (NOTE: it is a good idea to use as low a profile battery as possible to conserve trunk space.) Battery can be secured to floor with a rubber hold down strap available at most hardware or auto supply stores. Drill 1/4" holes through floor at ends of battery and install 1/4" eye bolts through floor with a flat washer and nut on each side. Fasten rubber strap to these to secure battery. Remove battery.

BRAKE FLUID RESERVOIR

☐ The VW brake fluid reservoir is mounted
to the floor of the trunk on the driver's
side of the gas tank flange. Rear mounting hole is 7" from rear corner.

Drill two 1/2" holes for line fitting 1 1/2" apart; secure reservoir to floor. Drill a 3/16" hole in flange on reservoir without hole. Drill two 1/8" holes through fiberglass and secure to floor with No. 8 x 3/4" hex washer head self-tapping screws.




Figure 11




Figure 12

HOOD SUPPORT ROD

- from the hood mounting surface, Drill the battery box on the driver's side of Measure back 4" from the front wall of ment for hood mounting rod. the luggage compartment and down 3" 1/4" hole through side of compart-
- ware. Lock nut is on the outside of the rod to trunk wall with supplied hard engages recess in bottom of hood. Secure trunk. 5" up from mounting threads so it Bend rod toward the center of the car
- mounting hole and install on side of auto supply store. Cut off outer top rubber tip on end of rod. trunk with a 1/4 x 1" carriage bolt, Obtain a 1/4" metal wire clamp at an as a retainer near end of rod. Install flat washer, lock washer and nut. Install

HOOD HANDLE - STANDARD ASSEMBLY ONLY

- Attach Speedster emblem to hood handle. Remove studs from handle and position on the center of the hood with the front edge of the handle 2 1/2" from front edge of hood. Draw a line around mounting surfaces with a grease pencil.
- Mark hole locations on hood. Drill 1/4" hole for front mounting stud. Drill two 5/32" holes for rear studs. Secure handle to hood with nuts provided. Use flat washers under nuts. DO NO OVER TIGHTEN.

STANDARD ASSEMBLY ONLY

- Draw a straight line from front fender well to rear fender well 1 1/2" below and parallel with door opening on both sides of the car. This is the center of the lower decorative molding. Remove rubber center strip from decorative molding and mounting screws. Mark hole locations and drill five 3/16" holes in each side.
- Slide rubber gasket into extrusion on rear of molding. Insert studs through holes. Secure with nuts provided using No. 10 washers in front of them. DO NOT OVERTIGHTEN.
- Push rubber center strip back into position.




Figure 13

DASH PREPARATION

- The Speedster dashboard has dimple marks indicating hole center locations for the preferred instrument layout utilizing the gauges available from our factory. If you prefer a different arrangement or if you decide to use other gauges, position the instruments as desired and cut or drill appropriate holes. Use a sabre saw to cut speedometer and tachometer holes. Finish with an electric drill and rotary rasp.
 - Cut smaller holes with a hole saw or drill bit.
 - Using the scribed holes as guides, drill 3/4" holes through the dashboard on each side for the windshiled mounting posts.
- Remove any rough edges from the bottom of the dashboard by sanding or grinding. Lightly sand the top surface
- of the dash behind the windshield mounting line and the front upper area above the line on the front passenger side of the dash. This is where the dash upholstery will be cemented.
- If you should decide to install the optional VDO gauges that are available from our factory, refer to VDO layout.




Figure 15

IV-14

DASH UPHOLSTERY

- dash. Allow material to fit the forward of the windshield line.
- Apply 3M spray 90 adhesive to both surfaces. Do not apply cement to area in front of windshield line. Stretch and smooth into position until a wrinkle-free surface is obtained.
- Cut upholstery material to fit the
- three rubber trim pieces. Fasten the material to the trim pieces with contact cement. **NOTE:** You can staple the material into the back of the rubber trim.
- Drill four 3/16" holes through the dash for the studs on the curved trim piece. Attach trim piece loosely with 3/16" nuts, flat washer and lock washers. Insert the lip of trim bead between
- the dash and trim piece and tighten nuts to hold in place.
- Apply adhesive to the two small trim pieces. Glue into place sliding the trim piece behind the top edges.
- Cut out holes for defroster vents and cement into place.





Figure 16

DECORATIVE ROLL BAR (OPTIONAL)


- Place left and right roll bar support plates against back inner sides of frame uprights. Holes in angles on supports should be facing the rear of car and support plate should angle in and upward to meet the body at the inside of the fender well. Bottom edge of angle rests against frame cross member. Clamp in place temporarily.
- Place roll bar in car as far back as possible with support legs extending toward rear and front mounting plates resting on front of seat area. Tape a wood board or other suitable straight piece across car at rear of doors. Adjust roll bar until measurement between wood straight

- edge and bar is equal on both sides. Mark hole locations on fiberglass.
- Remove roll bar and drill 3/8" holes through fiberglass at mounting locations. Drill through plate on frame below rear holes on front mount. Mark hole locations on roll bar support plates. Remove from car and drill four 3/8" holes in each support. Drill 3/8" holes through rear frame upright where angles of supports bolt.
- NOTE: it is not necessary to bolt roll bar at forward hole of front mount. If you decide to use this hole do not drill all the way through cross member.

- Drill only through top surface and secure with a lag bolt.
- Mount roll bar support plates to chassis with $3/8 \times 2 \ 3/4$ " hex head bolts, flat washer, lock washer and nuts.
- Mount roll bar to plate on support with $3/8 \times 1 1/2$ " hex head bolts with flat washer, lock washer and nuts. Mount front plate with $3/8 \times 2 1/2$ " hex head bolts, flat washer, lock washer and nuts.
- NOTE: Shim under plates, if necessary, with washers. Do not attempt to pull pieces completely together.



IV-17



FIREWALL SPLASH APRON

- A splash apron should be fabricated and fastened to the firewall behind the engine location. While a number of different materials can be used we recommend that you obtain some black rubber stair tread material available at large hardware stores or home centers in 36" widths. You will need one square yard.
- Cut out the end of the shroud area on the firewall with a sabre saw, as shown.
- Cut material as shown and secure to the firewall with pop rivets or self-tapping screws. Allow rubber to extend 2" below bottom of side rear frame members.

HOOD HINGE TRIM

Take the left-over material from the firewall apron and fashion two retangular pieces 4 x 6" to fit around openings cut for front hood hinges. Slit material to accommodate width of hinge and glue in place with contact cement.

OPTIONAL DEFROSTER DUCTS

Cut out slots for the defroster ducts in the scribed areas on the upper dash surface behind the windshield mounting line. Use a sabre saw or an electric drill with a rotary rasp.

FUSE BLOCK PLATE

Plywood (4 x 1?"). Mount fuse flock and horn relay to plate. Attach to fiberglass under dash in front of frame member. Secure from trunk area with two 1/4 x 1 1/2" carriage bolts, flat washer, lock washer and nuts.

GAUGE INSTALLATION

- A Route wires for gauges through their appropriate holes (see wiring instructions). Connect gauges and install brackets to hold them in place.
- Attach wires to tag lights and taillights
- Connect wires to windshield wiper motor and windshield washer, if used.




Figure 19

DOOR LOCK INSTALLATION

- With a hacksaw cut the top half of the "U" shaped piece on each door latch, as shown.
- Mount the left and right locks to the metal door plates with 6 x 12mm 1 mm pitch flat head machine screws. Attach wire inside door handle release rod to hole in lower release arm.
- J Place door plates, with lock attached, into door cut outs. Trim fiberglass flange for clearance, if necessary. Mark
- hole locations and drill sixteen 11/64" holes through fiberglass flange on each door. Mount the plates to the doors with No. 8 x 3/4" pan head machine screws, with flat washer, lock washer and nuts.
- Attach striker plate to door lock and close latch. Hold door in full closed position. From inside of the car hold the top portion of the striker plate with a screwdriver, pushing forward so rubber on striker plate is in full contact with top of latch. Mark striker

plate position from inside with a grease pencil or other suitable marker. Open door and remove striker. Place against door opening, where marked. Drill four 1/4" holes through fiberglass. Mount striker plate to the body and backing plate with 1/4 × 3/4" flat head machine screws, lock washers and nuts. If necessary, adjust door by widening the holes in the fiberglass. Striker plate can be shimmed outward with metal washers.




Figure 20




Figure 21

IV-21

- Draw a straight line across the center of the door handle recess on the outside of the door. Place rubber gaskets against the body. The large gasket is located closest to edge of door that opens. Mark hole centers 5" apart. With a 1" hole saw, cut the large hole. Drill a 3/16" hole for the small mounting hole. Attach handle to door with the large nut provided and a No. 10 x 1/2"
 - round head machine screw, with flat washer, lock washer and nut.
- Thread one No. 10 locknut onto the release rod on the door handle. Slide slot on tubular release arm over the release arm at the top of the lock. The release rod of door handle goes through the upper hole in the arm. Mark hole location on the inside lower center of the

- door. Drill a 1/4" hole and secure tubular arm to door with a $1/4 \times 1$ " flat head machine screw with flat washer, lock washer and nut. Countersink the hole in the fiberglass so screw is flush with the surface.
- Thread other nut onto door handle rod and adjust rod portion by turning nuts for proper action.




Figure 22

IV-22

- Mark position of inside handle release bracket 6 1/2" from top of door on center fiberglass door support. Position bracket on line so release lever faces down. Open portion of inner door handle is in line with top corner of lock plate. Mark hole locations. Drill 1/4" holes for mounting bolts and 3/4" hole for handle shaft.
- Attach inside handle wire release rod from the lock to the arm of bracket and bolt through the inside of door with 1/4 x 1" flat head machine screws with flat washer, lock washer and nuts. Countersink holes in the fiberglass so screws are flush with the surface.
- NOTE: As an alternative, you may use a piece of cable in place of the release rod. Obtain throttle cable and a throttle cable stop from an automotive supply store to secure cable ends together.
- After installation of the door upholstery, place handle and trim pad into position and secure with a cotter pin.





Figure 23



DASH STUDS FOR OPTIONAL TONNEAU COVER

- The studs behind the windshield for the tonneau cover must be installed prior to windshield installation. Even if you are not using a tonneau cover, we suggest that you install these studs.
- Twelve male studs with self-tapping screws are used. Drill 9/64" holes and
- screw into fiberglass, Do not overtighten, as you may strip the fiberglass material.
- Locate a stud 1" out on each side of the center dimple mark for the windshield hold down rod and 2" back from the windshield line on the body. Locate a snap in each corner of the dash, behind

the windshield post holes. Locate 4 more snaps on each side of the dash, between the snaps previously installed. Space snaps approximately 5" apart and 2" behind the line for the windshield frame.




Figure 1

ASSEMBLING THE BODY TO PAN

You will need a minimum of six people or a suitable lifting device to lift the body onto the frame.

NOTE: Prior to installation of the body, support the frame on jack stands, off the ground.

- Apply a 2" wide heavy bead of silicone sealer to all edges of the pan that contact the frame in the body. Three tubes, that fit into a caulking gun, are required.
- Lift body onto frame and adjust, so the holes in the mounting plates, at the rear, line up with the front holes in the shock towers on the chassis. Secure loosely with stock VW mounting bolts.
- Line the holes in the front mounting frame plates with holes in the VW pan. NOTE: Because of difference in pan shortening these holes may not line up exactly. If necessary, drill through pan and/or plate and secure with 7/16 x 1 1/2" bolts with flat washers on both sides and lock nuts.
- Secure rear cross member of frame to the pan with four original VW mounting bolts. You will need to cut out a small portion of each side of the fiberglass lower rear seat front. Some VW pans dif-

fer slightly and the holes may not line up. In this case, it will be necessary to drill 5/16" holes through the bottom of the pan and mounting plate flange on frame and secure with 5/16 x 2" hex head bolts with flat washers on both sides and lock nuts.

On the sides of the pan, drill 1/4" holes in the frame member through the

two front and rear pan holes, on each side of the car. Secure with $5/16 \times 1$ " hex washer head self-tapping screws.

Drill 5/16" holes through the middle three holes on the sides of the pan through the side plates on the frame. Secure with $5/16 \times 1 \, 1/4$ " hex head bolts with flat washers on both sides and lock nuts.




Figure 2

V-3

FRONT BODY SUPPORT


- Place lower portion of front body support into position by sliding studs on top of front axle through holes in support. The closed portion of the angle faces forward.
- Two spacers made from 3/4" round pipe approximately 1/4" thick and 1/2" long are placed over the studs and secured with original VW mounting bolts. The top portion of the body support is bolted in place after the body is installed on the pan.

SPARE TIRE MOUNT BODY SUPPORT

- Place the top portion of the front body support into position and secure to lower portion of support with two 3/8 x 1" hex head bolts, flat washers on both sides, lock washer and nut.
- Measure 3" back from the center of the rear battery box wall on the flat portion of the fiberglass in front of the gas tank recess. Mark location. Measure 6" to the left and right on this point, and mark. Drill three 5/16" holes through fiberglass and body support.
- Secure body to support with $5/16 \times 1 \cdot 1/2$ " carriage head bolts with flat washer, lock washer and nuts.

If you desire, a spare tire hold down rod can be fabricated and attached to the center carriage bolt, as shown.

NOTE: Because of space limitations, a standard spare tire won't fit in the luggage compartment. The easiest solution is to use a late model, 15" temporary use only, T125/T0D15, spare tire on a 4 1/2" VW rim.



BUMPERS OR OPTIONAL NERF BARS

Slots must be made in the rear of the body for the bumper brackets. Draw a line with a grease pencil at the exact center of the body below the license plate bracket down to the bottom lip of the body. Do the same at the front below the center of the hood opening. Mark body 13 1/2" to each side of the line at the rear and to each side of the line at the front.

The center of the slots at the rear measures 4" above the lower lip of the body. The center of the front bumper slots measures 3" above the bottom lip. Draw a line 1" above and 1" below these points.

Drill 1/4" holes at the top and bottom of line. With a sabre saw cut out sides between the holes for your slots. Finish with a file.

The rear bumper supports are placed


against the rear frame cross member with the holes in the angle facing down. Line up mounting plate on support with the slots cut in the body. Drill 3/8" holes through the cross member and secure with $3/8 \times 2 \ 3/4$ " hex head bolt, with flat washer, lock washer and nuts.

If using the optional nerf bars slide mounting plate through slots in the body with the long end of the chrome tube facing upward. Leave 3" of the chrome mounting plate between the bar and body. Mark hole locations and drill 3/8" holes through plate on bumper bracket supports. Attach nerf bars to support with 3/8 x 1 1/2" hex head bolts, flat washer, lock washer and nuts.

For standard rear bumper, place the shorter bumper brackets through the body slots with the longer mounting tab

of bracket pointing toward the center of the car. Clamp brackets in place against supports temporarily. Hold the rear bumper (shorter bumper) in position and mark the hole locations on the inside of the bumper. Drill 5/16" holes where marked.

Pull the black plastic center molding from the rear decorative bumper trim. Remove the bolts and clamp in place along center of bumper. Drill 3/16" holes through the bumper. Slide the small molding into channel on the back of the trim piece and secure to bumper with hardware provided. Drill 5/16" holes through the trim strip for the bumper mount bolts. Secure bumper to brackets with 5/16 x 1" pan head bolts. Secure through inner bumper bracket holes only with flat washer, lock washer and nut. Press outer black



molding back into trim.

- Loosely bolt the front bumper support brackets to the torsion tubes on the front axle with $5/16 \times 2 \ 1/2$ " muffler clamps provided. If necessary, shim clamps between bracket and torsion tube with bottom portion of muffler clamps.
- Place the front bumper brackets (longer) with the longer bumper mounting tab facing the center of the car through the slots. If using nerf bars, slide into position with the long end of the bar pointing upward. Line up with bumper supports and bolt securely in place. If using nerf bars, bolt to supports with
- 3/8 x 1 1/2" hex head bolts, flat washer, lock washers and nuts.

 Mount standard front bumpers exactly

as you mounted the rear.

If installing optional bumper guards, drill 5/16" hole through outer hole on bumper bracket through trim strip and rubber molding. Secure stud with 5/16" nut, flat washer, lock washer and nut. Shorten stud, if necessary, with a hack saw.

STEERING COLUMN

- Attach the adjustable column bracket to the mounting tab on the frame cross member behind the dash with a 5/16 x 3" hex head bolt, flat washers on both sides, lock washer and nut.
- J With a sabre saw cut a 2 1/2" slot in the fiberglass bulkhead below the rear portion of the gas tank. The center of
- this slot is 2 1/2" from the lip of the gas tank cut out.
- Mount steering shaft to steering box with original hardware. Mount steering column to adjustable bracket with 5/16 x 1 1/2" hex head bolts, flat washers, on both sides, lock washer and nuts.
 - NOTE: If your car is equipped with a switch for wipers and washer, cut the lever on the switch flush with the column.
- On pre 1968 VW's a provision for the ignition switch must be made in the dashboard.




Figure 7

DOOR WEATHER STRIPPING

- Install 1/4 x 3/4" foam weather stripping to the bottom of door opening and latch portion of door opening where it contacts door.
- J Attach a piece of weather stripping to hinge side of door.

FRONT FENDER PANELS

- Trim the front fender panels, as necessary, to obtain a proper fit. Grind gel coat from edges that contact the fiberglass inside of the fenders.
- J Position panels against the wheels side of the front bumper support brackets. Drill 3/16" holes through panels into bumper support brackets. Secure with 1/4 x 3/4" hex washer head self-tapping screws. You may use pop rivets, if you desire.
- The top of the panel will be fiberglass ed to the inside of the fenders later on.

HORNS

Install stock VW 12 volt horn on left fender panel. **NOTE**: If you prefer, a dual note European styled horn is available from our factory.




Figure 8

ENGINE COMPARTMENT INSERTS

- I Trim the engine compartment fiberglass inserts to fit.
- The smaller insert seals the rear inside of the body to the top of the rear cross member and should be flush with the front edge of the crossmember. Sand gel coat surface, as this will be fiber-glassed in place later.
- The lower insert fits against the bottom

of the rear crossmember and frame rails. The front lip of the insert fits against the engine cover plates. Trim, as necessary, for the best fit.

- Drill four 3/16" holes through the upper insert and the top of the rear crossmember. Secure with four 1/4 x 3/4" hex washer head self-tapping screws. You can pop rivet the upper piece into place, if desired.
 - Secure the lower insert to the bottom of the frame by drilling five 3/16" holes through insert and the bottom of the frame. Attach with five $1/4 \times 3/4$ " hex washer head self-tapping screws.
 - Use a piece of weather stripping or rubber to seal spaces between engine closure plates and insert.




Figure 9

V-11

GLASSING THE BODY

- Areas to be fiberglassed are:
- Hood support bracket cover boxes to body, sealing trunk compartment from passenger compartment.
- Top of front fender panels to body.
- Sides of body along doors to VW pan.

Rear of body at seat base to pan.

Around steering column cut-out in bulkhead.

- Steering column trim piece.
- Check to make sure all gel coat has been removed from any areas to be fiberglassed. All parts should be clean and dust free. Sand surface of any plastic pieces that are fiberglassed.
- Cut strips of fiberglass matting to fit areas to be glassed. Allow at least a 3" overlap between adjacent strips. When joining separate pieces allow fiberglass to extend 4-6" on each surface.
- Mix resin according to the manufacturer's instructions. Do not add too much hardener.
- To protect steering column from adhering to fiberglass, cover with polyethylene film. This will not stick to the fiberglass and can be removed after the fiberglass cures. Any heavy plastic food storage bag will work.




Figure 10

GAS TANK MODIFICATION

The VW gas tank will have to be modified for use on the Replica. For 1967, or earlier, fuel tanks, the filler must be moved to the opposite corner. Super Beetle tanks cannot be used.

Before performing any modifications do the following:

- Drain all gasoline from tank. Fill tank with detergent and water solution. Agitate tank and drain. Refill with soap and water solution, right to the bottom of the filler neck.
- For '67 or older tanks, cut filler neck off flush with tank. With cap still on filler, cut filler neck down just below vent fitting. Weld shortened filler neck back onto tank.
- NOTE: WE RECOMMEND THAT THIS PROCEDURE BE DONE BY A SHOP THAT IS EXPERIENCED IN WELD-

ING GAS TANKS. ANY GAS TANK
THAT HAS HAD GASOLINE IN IT IS
POTENTIALLY DANGEROUS. THIS
IS TRUE FOR ALL GAS TANKS.

- For '68 or newer tanks the filler opening must be moved to the opposite corner of the tank. On the raised flat spot, opposite the filler neck, cut a 2" hole, using a hole saw. Save the plug. Cut the filler neck down just below the vent fitting and save. Cut remaining tube on tank off just above tank. Weld shortened neck piece back onto tank.
- Plug original filler hole with 2" plug, saved from opposite corner of tank. Weld in place.

GAS TANK INSTALLATION

Attach a length of neoprene gas hose to bottom of tank and secure with a hose clamp. Attach length of fuel tube to vent fitting.

- Apply foam weatherstripping to lip of gas tank cut-out.
- Apply silicone to bottom of gas tank flange and set in place. Position original tank retainers on sides of tank and drill into fiberglass (5/16" drill bit). Secure with 5/16 x 1" carriage bolts, flat washer and lock nut.
- Drill a 1/2" hole in the fiberglass floor next to filler neck. Attach an 18" long piece of vacuum or fuel hose to the vent and pass through hole in floor and down front fender well. Secure to the inside of the fender well with a cable clamp.




Figure 11

TANK POCKET

V-14

PLUG - WELD IN PLACE

SPEEDOMETER CABLE

- J Obtain a VW speedometer cable No. 211,9578094 from a VW dealer or use original.
- Modify speedometer cable as follows: Grind off protrusions holding knurled mounting nut to cable. Slide mounting nut off cable. Replace with nut supplied with our gauges. (Other gauge sets may use different arrangements.)
- ☐ Route speedometer cable along the front harness and attach to the front wheel on the driver's side of the car.

STEERING WHEEL (OPTIONAL)

Attach steering wheel to adapter with screws provided. Fit wheel to column and retain with original VW nut. Attach horn button wires and press in place.





Figure 12

WINDSHIELD INSTALLATION

) (
and slip windshield posts into holes. Draw a line along the body in front of the lower rubber windshield extrusion. NOTE: Draw line 1/8" in from edge of rubber.	edge of windshield. Hold windshield in position on the body	with a rubber mallet. Mark and cut sides of trim even with	Place upper aluminum trim onto windshield. Bend as necessary for best fit. Do not force piece. Tap, if necessary,	windshield trim. Drill a 1/4" hole for support rod.	edge of windshield. Cut flush at edges.	Slide rubber U channel extrusion onto upper windshield edge. Use rubber adhesive to secure to glass.
Drill a 1/4" hole for the windshield support rod, through the top center of the dash 3" behind the front edge of the lower trim piece.	holes through the flange and fiberglass and secure lower trim to the body with twelve 1/8" pop rivets.	to line drawn on the body. Pull up dash upholstery so mounting flange rests flush against fiberglass. Drill 9/64"	the top holes. Bend lower windshield trim to conform	10 x 3/4" stainless steel oval head machine screw, through the bottom holes. Use No. 10 x 1/4" screws through	through trim for post screws. Use a 10-24 tap to thread holes. Attach	Mark windshield post hole locations on upper aluminum trim. Remove windshield from car and take off upper trim Drill 11/64" holes
)	C			
Apply clear auto sealer 3M - 08551,or equivalent, to outer lip of lower windshield extrusion and windshield trim.	USE CAUTION. Tighten in rotation. First tighten the support nut partially. Next tighten the post bolts. Then	er to threaded portion of rod under the dash.	Place support rod into hole in dash and hole in upper windshield trim. Attach nut, flat washer and lock wash-	head bolts with a flat washer under the head.	into position on car; slip spacers over post ends from below the dash and loosely secure with 3/8 x 1 1/4" hex	Cut two 3/4 diameter pieces of aluminum tubing with a 30° taper on one end for windshield post spacers. Place windshield with posts attached



MOTOR INSTALLING WINDSHIELD WIPER

one from an auto supply house. Be Obtain windshield wiper motor from a sure to specify a 12 volt motor. Volkswagen Beetle, or order a new

- spindles of the wiper (15 3/4"). Drill two 3/8" holes in the recesses on the body to match the distance between
- Secure with original spindle nuts and washers
- \Box position. posts when wiper is in the full down Mount wiper arms and blades to spindle

WINDSHIELD WASHER - OPTIONAL

available from our factory. the Replica. Because of space limitations we A variety of windshield washers will work on have a small unit with a flexible reservoir

- mark on both sides and mark nozzle lo-With a grease pencil draw a straight nozzles with hardware provided. cations. Drill 5/16" holes and mount back from the hood opening toward this the center of the car. Measure 2 1/2" line 4" in from each wiper post toward line between wiper post spindles. Mark
- cate mounting bracket on the center of Open luggage compartment cover and lo-

- Drill two 1/4" holes and secure bracket with 1/4 x 1" hex head bolt with lock the rear wall 1" down from the top. washer, flat washer and nut.
- the motor side for the washer hose and rear wall of the luggage compartment on Drill a 3/8" hole at the bottom of the wires.
- Follow the instructions included with the unit for hose connections.




Figure 14

V-18

Connect the red/black 10 gauge (No. 27) lead in the instrument harness to the power input terminal on the fuse panel (fuses 5-12). Connect the violet (No. 7) wire from the main harness to a power input terminal on the fuse panel (fuse 5-12 side).

Steering Column Connections - Connections are made from various wires located on the VW steering column to wires from the instrument harness. Some wires on the VW are not used and should be taped securely out of the way. If your steering column has a provision for a dimmer switch the wires may be used for a windshield washer.

Connect 10 gauge yellow (No. 17) lead from the battery harness to red/black 10 gauge wire from the VW

ignition switch

Connect the 10 gauge red/black (No. 27) lead from the instrument harness to the 10 gauge black VW ignition switch wire.

Connect the 10 gauge red (No. 28) wire from the instrument harness to the 10 gauge red VW ignition switch wire.

Connect the green/white (No. 30) lead from the instrument harness to one side of a 12 volt flasher to the steering column.

Connect the green/black/white wire from the VW signal switch to the other side of the flasher.

Connect the green (No. 5) lead from

the instrument harness to the green/ black wire from the VW turn signal switch.

Connect the orange (No. 6) lead from the instrument harness to the black/ white wire from the VW turn signal switch.

Connect the yellow/white (No. 29) lead from the instrument harness to the brown or horn wire on the VW column.

Secure the black harness wire to the frame next to the steering column for ground.

Additional accessories can be added easily. Extra terminals are provided on the fuse panel.




Figure 7

VI-11




Figure 8

VI-12

WIRING HARNESS INSTALLATION

There are a number of choices available in wiring your assembly.

- However, extensive modifications are necessary. In addition, a separate harness will have to be fabricated if you are using custom gauges.
- A complete wiring harness can be fabricated by a professional or by yourself, if your knowledge of automotive wiring if sufficient.
- Many people chose our wiring harness, specifically designed for the assembly. It accommodates all accessories and custom gauges. Step-by-step instructions make it easy to install.

- The harness should be placed on the car at this point. Connections can be made to components as they are installed, following the instructions furnished with the harness.
- The instrument portion of the harness is fastened to the top of the front cross-member behind the dash area. The front harness extends straight forward on the driver's side of the car. A 3/4" hole is cut through the bulkhead into the upper inside of the fenderwell. The harness is secured to the inside of the fender well just below the luggage compartment cable release housing that is fiberglassed to the body. It is secured to the body with wire clamps, available at auto supply stores. Split the harness at
- front just below the left head light housing and run the right portion of the harness across the car just forward of the battery compartment. Secure, as necessary, with wire ties or wire clamps.
- The rear portion of the harness runs down the front edge of the forward frame upright, just in front of the driver's door, to the floor. It then extends back along the pan and exits through a 3/4" hole, drilled through the corner of the seat base. The wires run along the frame and then branch to the left and right taillights and engine connections. Secure with wire ties or cable clamps. Keep the wires away from sharp objects and edges.




Figure 1

WIRING

Before you start the wiring on your assembly, we suggest that you have the following tools and supplies on hand.

TOOLS:

Good quality wire strippers
Good quality terminal crimping tool
Straight edge razor knife and extra blades
Self powered test light
12 Volt test light

SUPPLIES:

Proper terminals - butt connectors, ring terminals, female disconnects, splice connectors

Electrical tape
Wire ties
Wire clamps

WIRING HARNESS

The optional factory wiring assembly contains a 3 piece harness consisting of the battery, cable starter harness, the instrument harness and the main harness. The main harness connects to gauges, fuses, steering column wires and instrument harness wires behind the dash board. Then the harness branches off into 3 main divisions: the front branch, engine branch and rear branch. Each branch divides into other branches and connections. The starting point will be the steering column. Since the main harness runs from one end of the car to the other, it is more efficient to run the branches to their locations and make all the connections

that apply to the branch. Then come back to the steering column and make the appropriate connections.

NOTE: If using VDO gauges you will need a different wiring schematic. Call our Technical Department for new VDO Schematic.

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	=	10	9	00	7	6	5	4	2	2	1	NO.
ORANGE 10G	GREEN -	YELLOW	RED 10G	RED	VIOLET	BROWN	BLUE	GREY	RED -	WHITE .	WHITE -	RED	YELLOW	YELLOW 10G _	RED+	YELLOW	RED	ORANGE	BLUE -	RED	RED	RED	GREY	VIOLET	ORANGE -	GREEN -	WHITE	BROWN	BLUE -	BLACK	COLOR
NONE	WHITE	WHITE	NONE	BLACK 10G	WHITE	WHITE	YELLOW	- BLACK	NONE	NONE	RED	BLACK	NONE	NONE	NONE	BLACK	GREY	BLACK	BLACK	BLUE	YELLOW	WHITE	NONE	NONE	NONE	NONE	GREEN	NONE	NONE	NONE	MARKING

MAIN HARNESS ENGINE BRANCH

The engine branch runs along together with the rear branch from the steering column area over to the left inside of the car and down to the floor, then back and out of the body at the rear seat base. The two wires from the

back up light switch run over to the switch located on the transmission. The harness runs along the frame rail then the engine branch runs up and into the engine compartment. Secure the harness to the frame and fender well area, where necessary, with wire ties or wire clamps, available at auto supply stores.

- Transmission Back-Up Switch Connect blue/black (No. 12) lead to back-up switch on transmission. Connect red/black (No. 19) lead to other terminal on transmission switch. NOTE: These two leads are interchangeable.
- Senders Connect red/blue (No. 11) lead to the oil pressure on top of the engine. Connect red/yellow (No. 10) lead to the oil temperature sender at the bottom of the engine. NOTE: Make sure you use the appropriate senders for the gauges being used.
- Coil Connect violet (No. 7) lead to positive (+) side of the coil. NOTE: Electric choke wires to the carburetor(s) also connect here. Connect grey (No. 8) lead to the negative (-) side of the coil. Also connect the green wire from the distributor to this terminal.
- Voltage Regulator Connect the 10 gauge red/white (No. 9) lead to the battery (B+) terminal on the voltage regulator. NOTE: If you have a late model VW the alternator and regulator are combined. In this case, connect the 10 gauge red/white (No. 9) lead directly to the post on the alternator.

- Generator If your car has a separate regulator, fashion wire and make connections between the two. Connect the D+ terminal (armature) on the regulator to the D+ terminal on the generator. Connect the DF terminal (Field) on the voltage regulator to the DF terminal on the generator. Run a wire from the ground screw on regulator to ground screw on generator.
- Alternator If your car is equipped with a separate voltage regulator and alternator use the stock plug and wires to connect the two.

J Ground - The black (No. 1) lead at the intersection of the engine and rear harness is secured to the frame. NOTE: Make sure all dust, paint, rust, ect. is cleaned away where the ground connection is made. This completes your engine connections from the main harness.

MAIN HARNESS - REAR BRANCH

- The rear branch runs back along the frame side rail to the left taillight, then along the rear frame member to the license plate back-up light, then over to the right taillight. Secure harness to frame with wire ties or wire clamps.
- Left Taillight Connect the orange (No. 6) lead to the signal light. Connect the brown (No. 3) lead to the taillight. Connect the white/red (No. 20)

- lead to the brake light. The black (No. 1) lead is the ground and is connected to a taillight mounting stud.
- Back-up Tag Light Join the two tag light wires (same color) on the license plate light and connect the brown (No. 3) lead to them. Connect the red/black (No. 19) to the back-up light wire. The black (No. 1) lead is the ground and is connected to a mounting stud.
- Right Taillight Connect the green (No. 5) lead to the right signal light. Connect the remaining wires the same way you connected them to the left taillight.

This completes the connections at the rear of the harness.

MAIN HARNESS - FRONT BRANCH

Run the front portion of the main harness out of the driver's compartment just forward of the far left upper frame member into the wheel well. Run the wires along the cable release housing for the luggage compartment cover. The small three wire branch runs down to the brake switch on the master cylinder. The rest of the harness runs along the front left fender well down to the left signal headlight, and horn. Drill a hole through the left inside fender panel at the bottom and run the harness across to the right of the car. Secure the harness, wherever necessary, with wire

ties or wire clamps.

- Brake Light Switch Connect the orange/black (No. 13) lead to an outside terminal of the brake light switch on the master cylinder. Connect the white/red (No. 20) lead to the outside terminal. NOTE: Only one switch is used. We suggest the front switch. The center terminal on the switch is not utilized. The two leads are interchangeable.
- Ground Secure the black (No. 1) lead to the chassis.
- Horn Connect the yellow/black (No. 15) lead to the horn. The black (No. 1) lead is the horn ground.
- □ Left Turn Signal Connect the orange (No. 6) lead to the left turn signal wire. Connect a black (No. 1) lead to a stud on the light for ground.
- 3) lead to the left parking light. This is the bulb at the bottom of the headlight housing. Connect the blue (No. 2) lead to the low beam light. Connect the white/green (No. 4) lead to the high beam light. The black (No. 1) lead is the ground. NOTE: It is easier to splice the original VW headlight plug to the wires.
- Right Signal Light Connect the green (No. 5) lead to the right signal light wire. Connect a black (No. 1) lead to a




Figure 2





Figure 3



minal.	Oil Temperature Gauge - Connect the	Oil Pressure Gauge - Connect the red/ blue (No. 11) lead to the S terminal.	8) lead to the S terminal on the tach.	interchangeable.	the black (No. 1) lead to the other terminal on the light. The leads are	<	High Ream Indicator Light Connect	light switch. Connect the yellow (No.18)	headlight switch. Connect the brown	grey (No. 14) lead to post No. 1 on the	Hoadlight Switch Connect the rod	lead to the dimmer switch. Connect the white/green (No. 4) lead to the dimmer switch.	(No. 18) lead to the power in post on dimmer switch. Connect the blue (No. 2)	Dimmer Switch Connect the vollow	MAIN HARNESS - PASSENGER COMPART- MENT, INSTRUMENT, FUSE CONNEC- TIONS	ion i giri.	☐ Right Headlight, - Wire the same as the	mounting stud for ground.
is connected to.	(No. 21) lead to post 2 on the headlight switch. This is the same post the brown	at the left and move to the right. Instrument Lights - Connect the white	if you extend the wires for the instruments through their respective holes. Start working	The instrument harness is positioned behind the dashboard. It will be easier to work with	INSTRUMENT HARNESS	ness.	. 6) lead and green (No. 5) lead	The violet (No. 7) lead is connected to	horn relay.	lead to the power out terminal on the		Connect the red/grey (No. 14) lead to fuse 12 (power output) on the fuse panel.	fuse panel.	Connect the orange/black (No. 13)	t) on the	Connect the blue/black (No. 12) lead		Connect the 10 gauge red/white (No. 9)
(No. 23) lead to post 1 on the wiper switch. Connect blue/yellow (No. 24)	☐ Wiper Switch - Connect the grey/black	 lead to the ground terminal. Connect the white (No. 21) lead to the light terminal. 	Speedometer - Connect the black (No.	terminal. NOTE : The terminals on the signal lights are interchangeable.	the green (No. 5) lead to a terminal on the right signal indicator light. Con- nect a black (No. 1) lead to the other	☐ Right Signal Indicator Light - Connect	terminal.	on the left signal indicator light. Con-	☐ Left Signal Indicator Light - Connect	to the white terminal.	minal. Connect the white (No. 21) lead	Oil Temperature - Connect the red (No. 22) lead to the I terminal. Connect the black (No. 1) lead to the ground ter-	lead to the light terminal.	the black (No. 1) lead to the ground	Oil Pressure Gauge - Connect a red	minal. Connect the white (No. 21) lead to the light terminal.	black (No. 1) lead to the ground ter-	☐ Tachometer - Connect the red (No. 22)




Figure 6

lead to post 2. Connect brown/white by (No. 25) lead to post 3.

Fuel Gauge - Connect the red (No. 22) lead to the 1 terminal. Connect the black (No. 1) lead to the ground terminal. Connect the white (No. 21) lead to the light terminal. Connect the violet/white (No. 26) lead to the S N

Amp Gauge - Connect black (No. 1) lead to the ground terminal. Connect the white (No. 21) to the light terminal.

terminal

lead to the wiper motor ground. Connect the blue/yellow (No. 24) lead to the low speed post on the wiper motor. Connect the brown/white (No. 25) lead to the high speed post of the wiper motor.

☐ Fuel Tank Sender - Connect the violet/ white (No. 26) lead to the fuel tank sender. The black (No. 1) lead is the fuel tank ground.

Horn Relay - Connect the yellow/white (No. 29) lead to the horn relay.

INSTRUMENT HARNESS FUSE CONNECTIONS

Horn - Connect a wire (Not Supplied) from the horn relay power post to power out side of fuse No. 4.

Windshield Wiper - Connect the grey/

black (No. 23) lead to the power out side of fuse No. 6.

Instrument - Connect the red (No. 22) lead to the power out side of fuse No. 7.

J Turn Signals - Connect green/white (No. 30) lead to the power out side of fuse No. 8.

INSTRUMENT HARNESS TO MAIN HARNESS

Signal lights - Connect the green (No. 5) and orange (No. 6) leads to the green and orange wires from the main harness.

BATTERY CABLES

A positive cable 10 ft. long is used to connect the positive terminal of the battery to the starter on the engine. A negative cable approximately 30" long is used as a ground cable from the negative battery terminal to the chassis. The short cable is available at any auto supply store.

Drill a 3/4" hole through the cross piece at the front of pan next to the tunnel on the passenger side.

Run the positive cable from the battery through the hole drilled through the battery compartment on the passenger side down between the torsion tubes on the front axle and back through the hole in the front cross piece. Run the cable next to the tunnel to the back of the

car and out through the hole in the rear cross piece. Protect cable with piece of rubber hose or a grommet where it goes through the crosspieces. Run cable up and over to the starter. Secure the cable, where necessary, with wire ties.

Run the negative cable from the battery through the hole in the driver's side of the battery compartment back down to the sub frame behind the brake hose mounting bracket. Drill a 5/16" hole through the fiberglass into the sub frame and attach cable terminal with 5/16 x 1 1/4" hex washer head self-tapping screw with large flat washer. Make sure you have a good strong connection.

POWER CONNECTIONS

The battery starter harness should be installed now.

along with the 10 gauge orange (No run a length of 10 gauge wire from the S gauge. Connect the red 10 gauge (No 31) wire. Connect the yellow 10 gauge with the ring terminal to the starter Connect the red battery cable (No. 16) the S terminal on the amp gauge. Also main harness is already connected to red/white 10 gauge (No. 9) lead from the the S post on the amp gauge. The (No. 31) to the I post on the amp Connect the 10 gauge orange wire (No. 17) wire to the starter solenoid 28) lead in the instrument harness to input side of the fuse panel (fuses 1-4) terminal on the amp gauge to the power

Connect the red/black 10 gauge (No. 27) lead in the instrument harness to the power input terminal on the fuse panel (fuses 5-12). Connect the violet (No. 7) wire from the main harness to a power input terminal on the fuse panel (fuse 5-12 side).

Steering Column Connections - Connections are made from various wires located on the VW steering column to wires from the instrument harness. Some wires on the VW are not used and should be taped securely out of the way. If your steering column has a provision for a dimmer switch the wires may be used for a windshield washer.

Connect 10 gauge yellow (No. 17) lead from the battery harness to red/black 10 gauge wire from the VW

ignition switch

Connect the 10 gauge red/black (No. 27) lead from the instrument harness to the 10 gauge black VW ignition switch wire

Connect the 10 gauge red (No. 28) wire from the instrument harness to the 10 gauge red VW ignition switch wire.

Connect the green/white (No. 30) lead from the instrument harness to one side of a 12 volt flasher to the steering column.

Connect the green/black/white wire from the VW signal switch to the other side of the flasher.

Connect the green (No. 5) lead from

the instrument harness to the green/ black wire from the VW turn signal switch.

Connect the orange (No. 6) lead from the instrument harness to the black/ white wire from the VW turn signal switch.

Connect the yellow/white (No. 29) lead from the instrument harness to the brown or horn wire on the VW column.

Secure the black harness wire to the frame next to the steering column for ground.

Additional accessories can be added easily. Extra terminals are provided on the fuse panel.




Figure 7




Figure 8

UPHOLSTERY

In this section, you will install seats and carpet and will need 3M "90" spray adhesive and a good pair of scissors and some straight edge razor blades.

- Seat are best assembled on a large work bench or table of convenient height. You should cover the workbench with carpet remnants or similar material to protect the upholstery while you are working on the seats.
- Illustrations and instructions in this section contain some plywood and foam not supplied with your assembly. If you wish to use extra foam, it's available at your local auto upholstery supply house. However, the foam supplied with your assembly is adequate.

CARPETING

The carpeting kit consists of fourteen pieces of pre-cut and trimmed carpet, as shown. Lay out the pieces on the floor and check to be sure you have unpacked all the pieces. The seat back pieces are not used yet and should be placed aside for use later.

NOTE: Finished edges on the carpet are designed to be visible in the car. Unfinished edges are concealed by other parts and may have to be trimmed to fit.





Figure 1



Position the first piece against the trunk wall behind the accelerator pedal. Allow piece to extend several inches onto the floor. Apply adhesive and secure in place. Install the two small triangular pieces next.

- NOTE: Carpet is secured in place with a spray carpet adhesive such as 3M "90" brand spray adhesive. This adhesive is sprayed on the back of the carpet and the surface to which it will be cemented. Allow the adhesive to air-dry for about 30 seconds., then press in place.
- If necessary, the carpet can be picked up and moved to get a better alignment. You can also use contact cement. However, you have less capability to move the carpet in case of misalignment.
- Position the center piece over the shift tunnel. Glue in place starting at the front of the tunnel. Working toward the rear, cut an opening for the shift lever and another for the parking brake lever.

Finish cementing the remainder of the section to the tunnel.

- next, then the seat base carpet. Install the large rear seat back piece
- place. Position the carpet pieces at the side kick panels. Apply cement and glue in
- and on to the pan. The left and right floor sections are Position the door carpet pieces in position next and allow to extend down




Figure 3

HEATER HOSES

- The custom chassis has 2 inlet tubes for heater hose located at the rear.
- Obtain emission control hose 2 x 36" NAPA part No. 813-1313, or equivalent, available at any auto supply store, and four stainless steel hose clamps. Attach hoses from engine to frame.
- Defroster Hoses:

If using the optional defroster, install defroster hoses from frame outlets under the dash on each side of the car to the defroster vents behind the windshield.

MASTER CYLINDER TO BRAKE RESERVOIR

Attach master cylinder hoses to master cylinder reservoir and fill with brake fluid. Consult your VW service manual for bleeding information.

DIMMER SWITCH

Obtain a 12 volt floor mounted dimmer switch from an auto supply store.

- Mount the dimmer switch to the floor of the car, 4" behind the heater outlet opening, on the left main frame rail.
- Make all electrical connections to engine and transmission.

HEATER SLIDES (OPTIONAL)

- If using the optional heater defroster kit, position the stainless steel heater slides at cut-outs in the main frame rails at the bottom of the kick panels. Knobs to the rear of the car.
- Drill 1/8" holes using the slide as a guide. Secure heater slides in position with No. 6 x 1" stainless steel oval head self-tapping screws. As an alternative method, pop rivets may be used to secure slides.


SHIFT AND EMERGENCY BRAKE BOOTS


Paint emergency brake handle and shift handle with black paint.

- Obtain a standard shift boot from any auto supply store or our factory and install according to manufacturer's instructions.
- The original VW emergency brake boot is installed in the same manner as it was on the VW. New emergency brake boots are available from your local VW dealer.

WIPER ARMS AND BLADES

Attach Trico AL 60 heavy duty stainless steel wiper arms and appropriate blades, following instructions packed with the arms. These units are available from our factory. Attach arms when posts are in their full park position.





DOOR PANEL UPHOLSTERY

- Use heavy cardboard or light wood paneling and cut out pieces to attach door upholstery. Cut a 1/2" hole for door handle and open a hole for speakers, if installing a radio.
- Cut material to shape allowing 1 1/2" to extend around back. Attach with 3M "90" spray adhesive, or equivalent.
- NOTE: If desired, 1/4" foam can be attached to panels before upholstery is installed.
- Attach speakers to panels, if using, and connect speaker wires.
- ☐ Drill twelve 7/32" holes through panel and fiberglass lip on door and secure with No. 8 × 3/4" stainless steel self-tapping screws with washer.
- Attach door handle along with trim piece. Handle should face directly up when in the full closed position.

DOOR TOP TRIM

- Trim fiberglass edges of door top channels so edges are smooth and even.
- Fill ends of channel with epoxy putty, available at any hardware store. Putty should extend 3" toward the center of each end of the channel.
- ☐ Cut upholstery material to shape and attach to channel with 3M "90" spray adhesive.
- Drill three 7/32" holes in each channel and secure to door with No. 8 x 2" stainless steel trim screws, with washers. Glue ends of vinyl trim bead around edges of trim piece for a finished look.




Figure 6




Figure 7

FRONT SEAT FABRICATION

- Cut out the scribed oval areas on backs of fiberglass seat shells with a sabre saw.
- Attach black vinyl seat edge trim to the edge of each seat.
- Fabricate 1" wide strips from 1/4" plywood and attach to the inside of seat back and seat bottom. The back strips are centered 11" apart and the bottom strips are centered 9 1/2" apart. Secure to fiberglass shell with No. 10 1/2" round head wood screws or use poprivets as an alternative.
- Attach seat adjustment levers to outside upper seat slides with No. $10 \times 3/4$ " pan head machine screws with flat washers and lock nuts.
- apart.

 NOTE: Tracks must be parallel for free

movement.

- Mark hole location on fiberglass through holes in tracks. Drill 5/16" holes. Secure tracks to seats with 5/16 x 2" carriage bolts with flat washer, lock washer and lock nuts.
- NOTE: Two cup spacers are placed between the seat and track with a flat washer between them.

VII-8




Figure 8


- Apply 3M "90" spray adhesive to rear seat foam and fiberglass. Place foam in position with 1" of foam above the top of the fiberglass seat back.
- With a sharp knife cut 1" wide oval slots in the foam, through the oval cutouts in fiberglass.
- Slip oval flaps on the back of the upholstery fabric through the cut-outs in the fiberglass shell. Fasten inner side flaps to the wood strips with a staple gun. Pull the top center of the upholstery over the top of the fiberglass seat shell and glue to seat back with 3M "90" adhesive. Trim inner flaps where stapled.
- Apply adhesive to foam side pieces and glue in place.
- Staple inside edges of seat side upholstery to wood strips on seat base. Pull sides of seat upholstery around outer seat edge and glue in place.
- Pull upholstery tightly through oval cut outs in seat back and notch and trim fabric for best fit. Glue in place with 3M "90" spray adhesive.
- NOTE: As an alternative, 1/8" wood strips 1" wide can be fastened to the back of the fiberglass shell near the seat edge and the upholstery can be stapled to these strips.

VII-9

- Fabricate a seat base for the seat cushions out of 1/2" plywood. Base is 7 1/2" wide and 10" long. Center cushion base on seat bottom and attach to fiberglass shell with two 5/16 x 1 1/2" carriage bolts spaced 6"apart. Secure with flat washer, lock washers and nuts.
- pushing back of foam against seat back as far as possible. Secure foam with 3M "90" adhesive.
- Remove plywood cushion base and foam from the seat. Slip seat upholstery over foam Staple the side flaps to the bottom of the plywood. Staple the rear flap to the plywood. Leave the front flap loose.
- Attach seat cushion permanently into position. Pull front flap forward and over fiberglass shell and glue in place.

 Attach carpet backs to seat with spray

adhesive and trim for best fit.



REAR SEAT CUSHION

- ☐ Transfer dimensions to a piece of 1/2" plywood and cut out with a sabre saw.
- Glue a 2" piece of foam to plywood with 3M "90" spray adhesive. Trim foam for proper fit.
- J Attach rear seat upholstery to bottom of plywood with staples.

 J Install rear seat in car.





Figure 10



VII-12

Figure 11

SEAT INSTALLATION

NOTE: The following positioning of seats give the proper location for the average person. The location can be moved forward or backward, as desired, to meet your individual requirements.

- Locate the rear seat studs 11" forward from the rear seat base. Inside studs are 3 1/4" from tunnel. Hole locations can be marked on carpet by applying chalk to bottom of studs or by applying masking tape to carpet, then pressing down on seat.
- Drill 3/8" holes. Place the seats in place with large washers between the seat track and carpet.

 Check the position and bolt the seats securely in place with 5/16" nuts with

SEAT BELTS

lock washers and large flat washers.

While the stock seat belts can be used, if the brackets are straightened, we use smaller belts on the assembly. Available from our factory, these belts are installed with the seats. The rear studs pass through the holes in the brackets at the ends of the belts.

CARPET TRIM

- Position the long piece of aluminum carpet trim at the rear of the door opening on the body. Closed end of trim piece faces up. Trim bottom for proper fit.
- Shorter piece of trim fits on front inside edge of door opening on the body. Bend trim piece to follow contour of door opening. Trim bottom for proper fit.
- Drill six 7/64" holes for the front trim piece and seven for the rear. Attach with 6 x 1" stainless steel oval head self-tapping screws or with pop rivets.

DOOR SILL TRIM

- Place door sill trim pieces along inside edge of the bottom of each door opening on the body, covering edge of carpet. Shorten, if necessary.
- Drill nine 7/64" holes for each trim piece and attach with No. 6 x 1" stainless steel oval head self-tapping screws or pop rivets.




Figure 12

CONVERTIBLE TOP

the body.	on each side of the car. These supports are located on the sides of the car under the rear seat back carpet, approximately 3 1/2" behind the rear door edge trim and 2 1/2" down from the top of	Locate the threaded tubular bow support arms fiberglassed into the body	to slightly enlarge the holes in the latches.	and nuts. Countersink the heads of the bolts so they are flush with fiber-	Secure latches to bow header by drilling 11/64" holes through header and install No. 8 x 1" SS oval head machine	Attach latches to windshield and mark mounting position on each side of header.	Position fiberglass bow header on windshield frame.
) [[9]	
	the center snap arou lip. NOTE: Work from nating between each placed 5" apart.	Have a helper pull fo and install eight snap	center of the car aborear seat lip. Install on the top.	Center the top on the one snap stud in the	Secure the front bow arms and into the b $1/4 \times 1 \ 1/2''$ hex I flat washer on each sid	on the inside. The le on the bottom facin of interior.	arms with 1/4 x 1 through the arm and b

ow with a locknut ig the center rear ever on the arm is " hex head bolt

ow supports with head bolt with a to the top bracket

out 1" behind the e fiberglass at the he car and install a matching snap

m the center alterorward on the top os on each side of nd the rear body side. Studs are

a wrinkle-free finish is obtained and Pull top forward over bow header so inside of the car. mark position of top against bow from

Slide the longer metal top bow through

the forward loop on the convertible top. Slide the shorter bow through

Apply with 2011 (Goodyear) (Pliobond) adhesive or its equivalent to the fiber

Secure rear bow to the top bracket

the rear loop.


glue material around and inside channel 2" in front of fiberglass header and glass header and top. Sand header bow before applying glue. Trim material rubber weather stripping to inside of of header. Attach a piece of foam channel.

glass. Install a matching snap in each Be very careful to avoid windshield hole and secure with a pop rivet. NOTE: windshield trim. NOTE: Drill a 1/8" Install a stud on each side of upper forward flap.

side of the car for the rear side curthe flaps. tain flaps. Install a matching snap in Install an additional snap stud on each

TONNEAU COVER (OPTIONAL)

the front of the car. Start at the rear center and work toward Install snaps in tonneau cover to match studs on padded rolls and trunk lid.



PV3

SIDE CURTAINS

- Attach metal posts to the side curtains with the hardware provided.
- NOTE: Use rubber washers or 0 rings under carriage bolt heads to prevent overtightening.
- ☐ Drill 3/8" holes for support tubes in door trim roll and install tubes.
- Attach piece of rubber seal strip with flat 3/4" lip to the bottom of side

- curtain. Allow seal strip to extend 1" past each end.
- Place the side curtain in position with the top up. With a grease pencil mark curtain where ever it needs to be trimmed. Plastic should extend to outer lip of top and 1/4" behind windshield posts.

Carefully trim for proper fit, using a sabre saw with a very fine blade. Sup-

- port material when cutting to avoid cracking.
- Install rubber seal strip. Material with the flat rubber flange goes along the bottom as well as the rear and top. Cut a piece of rubber trim material with the tubular edge for front of windshield. Cut angles at corners where material meets and glue with Supergiue or equivalent.




Figure 14

SECTION VIII FINAL DETAILS

MIRRORS

Many types of mirrors can be utilized on the Replica. Mounting is a matter of personal preference. Illustrations are for mirrors available from our factory.

- Attach rear view mirror to the windshield support rod with the hardware provided.
- Attach outside fender mirrors to the fenders. Locate center of mirror(s) approximately 5" from the side of the luggage compartment opening, 3" forward of the rear corner. Fasten with hardware provided.

VERSION ONLY

- Clean surface of mounting location with acetone.
- Draw a light line with a grease pencil from the center of the door handle to the front and rear of the car. Extend line 33" on side of front fender and 35" on side of rear fender. Points of molding are at the front and rear of car.
- Cut pieces to fit front fender and remove backing and apply to surface.
 Cut pieces to fit the door. Remaining pointed piece runs along the rear fender.




Figure 1




Figure 2

RADIO

with side of the car below the dash. case. The radio is located on the passenger assembly. The optional factory unit comes A number of radios will fit the Replica а special mounting bracket and

- tapping screws. with 1/4 x 3/4" hex washer head selfdash. Drill two 7/32" holes and attach bottom of the crossmember behind the Position the metal mounting bracket in the appropriate location against the
- Install radio and cover.
- and door jamb for speaker wires. Drill holes through the top of the door

ANTENNA

- the car. of the fender on the passenger side of The optional antenna mounts to the top
- opening. Drill a 1/2" hole and mount antenna. 13 1/2" forward of the top of the door Mark hole location approximately
- the inside of the fender well. secure the mount on the power unit to If using the optional power antenna,

VIII-2

PASSENGER GRAB HANDLE (OPTIONAL)

A grab handle for the car is available from the factory as an option. It is for the convenience of passengers.

- Locate handle 6" from the end of the dash trim roll on the passenger side.

 The bottom of the handle contacts the bottom lip of the dash. The upper mounting hole lines up with the trim piece.
- Mark hole locations and drill two 1/4" holes. Secure with the hardware provided.

EMBLEMS

One emblem is furnished with the assembly. It can be mounted on the dash or front fender. If desired, an additional emblem can be obtained from the factory.

Preferred locations are on the passenger side of the dash or on the passenger side front fender, just forward of the door, above upper side molding on the standard model.

Position emblem in desired location and mark stud location. Drill five 1/8" holes and push into position. If the assembly should become loose, adhesive can be applied to the studs.




Figure 3

PRE-OPERATIONS CHECK LIST

☐ Engine oil level is correct.		☐ Brakes have been bled and adjusted		☐ All parts are lubed where required.		All bolts are tightened properly.	Before putting your car into service be sure: Transmission oil level is correct.
[
Tone sid is properly anglica.	Examt and is properly eligned	charging battery.	Battery is charged and alternator is		ed)	☐ Tire inflation is at 28 psi (recommend-☐ Headlights are adjusted.	Fransmission oil level is correct.
	С)					
requirements.	Car meets your state safety and emission		properly.	Horns and all safety items function		Headlights are adjusted.	All belts are tightened properly.

NUT AND BOLT LIST

- License plate holder to body (2 each)
 5/16 x 1" hex head cap screws with flat washers, lock washer and nuts.
 Taillights to body 6 No. 10 flat washers
- and lock washers.

 3 License and back up light to body.
- 3. License and back up light to body 2 No. 10 flat washer and lock washer.
- 4. Horn grilles to body 6 No. 6 flat washer and lock washer.
- 5. Turn signals to body 4 No. 10 flat washer and lock washer.
- 6. Deck hinges to deck lid (4 each) 1/4 × 1 1/2" hex head screws with flat washer, lock washer and nuts.
- 7. Rear deck hinge brackets to body $(4 \text{ each}) \ 3/8 \times 1 \ 1/2"$ hex head cap screws, lock washers and nuts. 8 flat washers.
- Deck hinge to bracket Two 3/8 x 1 1/2" hex head cap screw. 4 flat washers, 2 lock nuts.
- Deck lock to mounting plate (2 each)
 3/8 x 1 1/2" hex head cap screws; 4 lock washers and nuts, 4 flat washers.
- Lock pin to deck lid (2 each) 5/16 lock nuts and flat washers.
- Support pin to firewall 1 No. 10
 x 1 1/2" round head machine screw, flat washer, lock washer and nut.
- 12. Grille to deck lid 4 No. 6 round head stainless steel self-tapping screws.
- Headlight clip to body (3 each) No.
 10 x 1/2" round head machine screws with flat washers, lock washers and nuts.
- 14. Headlight housing to body (2 each)1 1/2" chrome or S.S. carriage bolts,

- flat washer, lock washer and nuts.

 15. Hood latch to hood (2 each) 5/16 ×
 1" carriage bolts with flat washer, lock washer and nuts.
- 16. Hood hinges to hood flange (4 each) 5/16 x 1" hex head bolts with flat washer, lock washer and nuts.
- 17. Hood hinges to hood hinge support bracket Two 5/16 x 1" hex head bolts with 4 flat washers and 2 lock nuts.
- 18, Hood hinge support brackets to frame (4 each) $5/16 \times 2 1/2$ " hex head bolts with flat washers, lock washers and nuts.
- Brake reservoir to trunk floor 2 No. 8
 x 3/4" hex washer head self-tapping
 screws.
- Hood support rod retainer bracket -1/4 x 1" carriage bolt with flat washer, lock washer and nut.
- 21. Hood handle to hood 2 No. 8 flat washers.
- 22. Lower door molding 10 No. 10 flat washers.
- Dash trim center piece to dash (4 each)
 3/16" nuts, flat washer and lock washers.
- 24. Firewall splash apron to firewall No. 8 x 3/4" self-tapping round head screws.
 25. Rear bumper support brackets to frame (4 each) 3/8 x 2 3/4" hex head bolts.
- Nerf bars or bumper brackets to bumper support brackets (8 each) 3/8 x 1 1/2" hex head bolt, flat washer, lock washer and nuts.

flat washers, lock washer and nuts.

- 27. Bumper molding to bumpers (4 each) 5/16 x 1" pan head machine screw with flat washer, lock washer and nuts.
- Bumper guards to bumper Four 5/16 flat washer, lock washer and nuts.
- 29. Fuse block pate to body under dash (2 each) 1/4 x 1 1/2" carriage bolts, flat washers, lock washer and nuts.
- 30. Roll bar supports to chassis (4 each) $3/8 \times 2 \ 3/4$ hex head bolts, flat washer, lock washer and nuts.
- Roll bar to support (8 each) 3/8 x
 1/2" hex head bolts, flat washer, lock washer and nuts.
- 32. Forward roll bar mount to chassis (4 each) 3/8 x 2 1/2" hex head bolts, flat washer, lock washer and nuts.
- Engine compartment inserts to frame -Fourteen 1/4 x 3/14" hex washer head self-tapping screws.
- Door locks to door plates 6 x 12mm
 1mm pitch flat head machine screws.
- 35. Door lock plates to body (32 each)

 No. 8 x 3/4" pan head machine screws

 with flat washer, lock washer and nuts.
- 36. Striker plate to reinforcing plate (8 each) 1/4 x 3/4" flat head machine screws with lock washers and nuts.
 37. Door handle to door (2 each) No. 10
- flat washer, lock washer and nut.

 38. Door release rod to door (2 each)

 1/4 x 1" flat head machine screw with

x 1/2" round head machine screw with

1/4 x 1" flat head machine screw with flat washer, lock washer and nut.
39. Door handle release rod to lock release rod - 4 No. 10 lock nuts.

- Inside door release mechanism to door -(4 each) 1/4 x 1" flat head machine screws with flat washer, lock washer and nuts.
- 41. Front subframe mounts to VW pan (4 each) 7/16 x 1 1/2" hex head bolts with 8 flat washers and 2 lock nuts.
- 42. Front and rear pan sides to subframe -Eight 5/16 x 1" hex washer head selftapping screws.
- 43. Sides of pan to frame side plates (6 each) $5/16 \times 11/4$ " hex head bolts with lock nuts, 12 flat washers.
- 44. Top body support to lower body support (2 each) 3/8 x 1" hex head bolt lock washer and nuts, 4 flat washers.
- 45. Body to body support (3 each) 5/16 x 1 1/2" carriage bolt with flat washer, lock washer and nuts.
- 46. Fuse block plate to body (2 each) 1/4 x 1 1/2" carriage bolts with flat washer, lock washer and nuts.
- 47. Steering column bracket to frame One 5/16 x 3" hex head bolt with lock washer and nut, 2 flat washers.
- 48. Steering column to steering column bracket (2 each) 5/16 x 1 1/2" hex head bolt with lock washers and nuts, 4 flat washers.


- 49. Carpet trim to body 26 No. 6 x 1" stainless steel oval head self-tapping machine screws.
- 50. Door sill trim to body 18 No. 6 x 1" stainless steel oval head self-tapping screws.
- 51. Heater slides to frame 8 No. 6 x 1" stainless steel phillips oval head self-tapping screws.
- 52. Dimmer switch to floor Two $1/4 \times 3/4$ " hex washer head self-tapping screws.
- 53. Fender panels to front bumper support brackets Ten 1/4 x 3/4 hex washer head self-tapping screw.
- 54. Plywood strips to front seats 48 No. 10 x 1/2" wood screws.
- 55. Seat adjustment levers to seat tracks (4 each) No. 10 x 3/4" pan head machine screws with lock nuts.
- 56. Seat tracks to seats (8 each) 5/16 x 2" carriage head bolts with flat washer, lock washer and nuts.
- 57. Front Seat cushion to seat (4 each)
 5/16 x 1 1/2" carriage head bolts with
 flat washer, lock washer and nuts.
- 58. Door panels to door 24 SS No. 8 x 3/4" self-tapping trim screws and washers.

NOTE: The nuts and bolts listed here may vary from our optional hardware kit. In addition, many options are supplied with their own hardware and because of variations, the hardware is not listed here.

- 59. Windshield post to upper windshield trim two No. 10 x 1/4" SS oval head machine screws; two No. 10 x 3/4" SS oval head machine screws.
- Windshield center support post to body one 1/4" nut, flat washer and lock washer.
- 61. Windshield posts to body (2 each) 3/8" and 1/4" hex head bolts with four flat washers.
- 62. Gas tank to body (4 each) 5/16 x 1" carriage bolts with flat washer, lock washer and nuts.
- 63. Rear bow to support arm (2 each) $1/4 \times 1$ " hex head bolts with locknuts.
- nuts.

 64. Front bow to support arm and support bracket (2 each) 1/4 x 1 1/2" hex head bolts with 4 flat washers.
- 65. Top latches to fiberglass bow header (4 each) No. 8 x 1" stainless steel oval head machine screws with flat washers, lock washers and nuts.

LOCK NUT		HEX HEAD WASHER SHEET METAL SCREW	SLOT DRIVE	PHILLIPS DRIVE
RING TERMINAL	CIO	ROUND HEAD	OVAL HEAD	
PUSH ON TERMINAL		SPRING LOCK	PAN HEAD	
WIRETIE	SCOTCH SPLICE	FLAT	CARRIAGE HEAD	
BUTT CONNECTOR		нех нот	нех неаd	



SPEEDSTER PART IDENTIFICATION

- (1) Dash Pad Set
- 4327 (1) Dash Pad Set
 - (1) Dash Pad Set
- Not Used
- (1) Left (1) Right Windshield Post
- <u>ი</u> თ (1) Left (1) Right Door Lock Mounting
- (1) Rear Engine Grille
- (2) Inside Door Handle
- 9 (2) Outside Door Handle
- 10. (2) Hood Hinges
- = Not Used (1) Left (1) Right Deck Hinge
- Hood Handle - Standard Model Only
 - (2) Headlight Support Bracket
- (12") 3/4 Aluminum Tubing
- (1) Rear Deck Lock Pin
- (1) Outside Door Handle Rubber Large

- 18. (1) Outside Door Handle Rubber Small
- (1) Logo Emblem
- 20. (2) Outside Door Handle Nut
- Front Emblem Standard Mode

39.

38

(1) License Holder (1) License Light

37. 36.

(1) Left (1) Right Rear Tail Light

(2) Door Striker Backing Plate

41. 40.

(4) Front Bumper Support Clamps

(1) Windshield Tension Rod

(2) Outside Door Release Rod

- (5 ft.) Lower Windshield Rubber
- (2) Convertible Top Latch
- (6 ft.) Top Windshield Rubber
- 25. Inside Door Handle Escutcheon
- (1) Left (1) Right Inside Door Release
- 27. 26. Left (1) Right Top Release Arm
- 28. (1) Left (1) Right Door Striker
- 29. (1) Left (1) Right Door Latch
- 30. (24 ft.) Seat "U" Channel
- (2) Inside Door Release Rod
- Upper Hood Latch Assembly
- (1) Deck Prop Pin (1) Deck Latch Assembly


- 43. 42. (2) Directional Lights (2) Horn Grille
- 44. (4) Seat Slides
- 45 (1) Left (1) Right Carpet Trim Short

(18 ft.) Upper Side Moulding - Standard

47. (1) Left (1) Right Carpet Trim Long


Model Only


- 48. (8) Seat Slide Washers
- 49. (2) Seat Slide Handles
- 50. (2) Door Sill Trim
- (1) Hood Prop Rod



- WINDSHIELD
- (B) LOWER RUBBER EXTRUSION
- STEERING COLUMN BRACKET

- FRONT INNER BUMPER SUP-





SUPER BEETLE CONVERSION UNIT (OPTIONAL)

The unit should be installed after the shifter assembly has been removed. With the Super Beetle conversion kit in place, it will be difficult to remove the shifter rod from the front of the car. See "Remounting The Gear Shift Lever".

Obtain a standard Beetle torsion tube assembly - complete with brake drums, shocks, steering box, steering control arm and steering damper. With the Super Beetle body removed from its chassis, measure 11 3/4" from the edge of the master cylinder mounting hole and scribe a mark around the chassis tunnel as shown in the illustration. With a hacksaw, cut along the scribe mark around the chassis tunnel. Remove and discard the nose section.

Fit the torsion tube support plate to the underside of the Super Beetle chassis. It may be necessary to cut or file a notch on either side of the chassis for a proper fit. Secure in place using the six bolts supplied with the kit (4 bolts 1/2 x 4" and two bolts 7/16 x 3") then finger tighten.

Remove the bolt holding the steering damper to the torsion tube assembly. It is not necessary to save this bolt.

1X-8

- Locate the Standard Beetle torsion tube assembly into the four slots of the torsion tube support brackets and secure with the two bottom bolts supplied with the kit. Fit the top plate to the Super Beetle chassis as shown. Using the two original bolts, secure finger tight. Next, insert two bolts supplied with the kit (1/2 x 5 1/2") through the upper holes of the Standard Beetle torsion tube assembly, securing the top plate to the rear of the torsion tube support brackets.
- Check measurement of wheel base on should be equal on each side. Refer to the center line of the front wheel axis each side of car. The measurement from equal wheel base measurements. to the left or the right until you achieve to the center line of the rear wheel axis shown in the illustration, and tighten. ers and nuts supplied with the kit, as 2" bolts, spacers, flat washers, lock wash Beetle chassis. Insert two sets of 1/2 x drill two 9/16" holes into the Super Torsion Tube Support plate as a guide, Using the remaining two holes on the this is accomplished, tighten all bolts. Figure 1. Shift the Torsion Tube Support to confirm that no shifting has occurred measurements on both sides of the frame At this time, recheck the wheel axis When
- □ Refit the Steering Damper using the 10mm x 64mm bolt and the spacer provided with the kit. Recheck all measurements and again tighten nuts and bolts.




Figure A2

FIBERGLASS CARE AND REPAIR

TYPES OF FINISHES

Parts are made of molded fiberglass. There are 3 types of fiberglass material finishes:

- 1. Gel Coat finish: This finish is made of a special pigment and blended polyester resin several thousandths of an inch thick.
- 2. Molded-in-Color finish: This finish is molded into the fiberglass material which is the same color throughout its thickness.
- Painted finish: This finish is painted on the natural color fiberglass material using standard painting procedure.

CARE OF FINISHES

The Gel Coat and molded-in-color finishes require minimum care and can be kept looking new by following these easy maintenance rules:

Clean, buff and wax the exterior periodically to renew finish.

An automotive wax type cleaner containing fine rubbing compound is suitable for removing minor scratches and scuffs. Scratches which are not removed by the rubbing compound can be removed by wet sanding with 400 grit sandpaper. Then wet sand with 600 grit sandpaper, rebuff and apply wax polish.

Care should be taken not to cut through the gel coat surface when rubbing. A power buf-

fer may be used with care or the surface may be buffed by hand, using a rubbing compound.

REPAIRS

Patch and fill in deep scratches, scars and small breaks.

Repair any major breaks as soon as possible to avoid any additional damage.

For damage to the gel coat finish, a can of Gel Coat of the same color and a small amount of catalyst is needed. For damage to the molded-in-color surface, a can of Filler Coat of the same color and a small amount of catalyst is needed. For deep holes, breaks, or gouges, some fiberglass mat and pre-accelerated polyester resin will also be required. Use M.E.K. (methyl ethyl ketone) catalyst.

The other materials including fiberglass mat, and pre-accelerated polyster resin are supplied in fiberglass repair kits which are available at most marine or automotive supply stores.

Damage to the painted type finish can be repaired by sanding, priming and painting using regular painting procedure.

SURFACE FINISHING

GEL COAT TOUCH-UP AND SURFACE REPAIRS

This type of damage may be classified as damage to the gel coat only, or a hole or

gouge that is deep enough to slightly penetrate fiberglass material. Repair as follows:

- 1. To be sure that the area to be patched is dry, clean and free of any wax or oil, wash with lacquer thinner.
- 2. Roughen the bottom and sides of the damaged area, using a power drill with a burr attachment. Feather the edge surrounding the scratch or gouge, being careful not to undercut this edge. (See Figure A)
- 3. A small amount of gel coat, the same color as the finish should be placed in a small can lid or on a piece of cardboard. Use just enough to fill the damaged area. If damage has penetrated through to fiberglass material, an equal amount of fibers, which can be taken from glass mat and shredded into small fibers, should be mixed with the gel coat using a putty knife of flat stick. Add three drops of catalyst per teaspoon of gel coat using an eye dropper. Be sure to mix the catalyst thoroughly for maximum working time. Maximum working time (pot life) will be about 15 to 20 minutes at which time it begins to "gel". (See Figure B)
- 4. Fill the scratch or hole above the damaged area about 1/16", working the material into the damaged area with the sharp point of a knife. Be careful to puncture and eliminate any air bubbles which may occur. (See Figure C)

NOTE: If fiberglass fibers have not been used in mixture, skip steps 5 through 7 and proceed with step 8.

- 5. When the patch feels rubbery to touch (10-15 minutes), trim the patch flush with the surface, and then allow to cure completely (30-60 minutes). Patch will shrink slightly as it cures, making a depression. (See Figure D)
- 6. Carefully roughen up the bottom and edges of the depression, using the electric drill with burr attachment, as in Step 2. Feather into surrounding gel coat; do not undercut.
- 7. Again mix a small amount of gel coat with catalyst do not use glass fibers. Using your

- finger or putty knife, fill the depression with gel coat 1/16" above the surrounding surface.
- 8. Spread the gel coat level with the surrounding area and allow to cure (30 60 minutes). (See Figure E) Gel coat can be covered with cellophane, if desired, to aid in spreading evenly. Remove cellophane after gel coat has cured.
- 9. Sand the patched area, using a sanding block with 600-grit wet sandpaper. Finish by buffing with fine rubbing compound such as DuPont No. 606 and waxing. Weather-

ing will aid to blend touch-up if a slight color difference can be observed. (See Figure F)

NOTE: Where surface color of part has changed due to weathering, color match of patch may not be satisfactory. In this case, entire panel must be sprayed.

Thin Gel coat with acetone (1 to 1 ratio) and spray panel, blending sprayed area into a radius or corner on the part. Use a touch-up spray gun such as the Binks Model 15. After Gel coat is hard, buff and polish sprayed area.




Figure 1

INDEX

Heater Slides (Optional)
Hoses
Headlights
Hardware And Fasteners1-6
HardwareIX-3
Glassing The BodyV-12
Gauge Installation
Gas Tank ModificationV-13
Gas Tank Installation
Fuse Block Plate
Front Seat FabricationVII-8
Front Fender Panels
Front Body Support
Firewall Splash Apron IV-18
Fiberglass Preparation
Fiberglass Care and Repair
Engine Cover (Rear Deck)
Engine Compartment Inserts
Emblems
Door Weather Stripping
Loor Top Trim VII-7
Door Sill Trim
Door Panel Upholstery
Door Lock Installation
Dimmer SwitchVII-4
Decorative Roll Bar (Optional)
Dash Upholstery
Dash Studs For Optional Tonneau Cover
Dash Preparation IV-14
Convertible Top
Considerations When Buying A Volkswagen
Carpet Trim
Carpeting
Bumper Or Optional Nerf Bars
Brake Lines
Brake Fluid Reservoir
Battery Compartment
Battery Cables
Assembling Body To PanV-2
AlliellidVIII-Z

Side Curtains VII-16
Shift And Emergency Brake Boots
Seat Installation
\$ at Belts
Scribe Lines
Rubber Trim And Brackets Identification
Removing The Volkswagen Body
Removal Of Clutch, Brake And Gas Pedal Assembly
Rear Suspension Adjustment
Rear Seat Cushion
Radio
Power Connectors
Preparation Of Chassis
Pre-Operations Check ListVIII-4
Passenger Grab Handle (Optional)
Parts To Be Purchased
Optional Defroster Ducts
Nut And Bolt KitIX-1
Modifying The Shift Rod
:
Mechanical And Chassis Preparation
Master Cylinder To Brake Reservoir
Main Harness Rear Branch
Connections
Main Harness Passenger Compartment, Instrument, Fuse
Branch
Main Harness Engine Branch
Lowering The Front End
standard Ass
1.
Instrument Harness To I. HarnessVI-10
Instrument Harness Fu Connections
Instrument Harness
Installing Windshield Wiper Motor
Horns
Horn Grilles And Front Turn Signals
rt Rod
lV-
ard Assembly Only
i rood cover (Euggage compartment cover)

INDEX

																				(SI	00	ellane	s (Miso	Tools And Parts (Miscellaneous)
Tonneau Cover (Optional)									*		*											onal).	(Opti	Cover
To Cut A Scribe Line							•	•															e Line	A Scrib
.IV-2				•	•				•			•					*							Taillights
.IX-8						•			•	*	*		•		_	Ω1	\preceq	-	D	0	-	on Ki	onvers	Super Beetle Conversion Kit (Optional)
.V-15					•										•							nal).	(Optio	Steering Wheel (Optional)V-15
.V-9					*				•		*		*	*		٠					:	:	īn	Steering Column
.IX-5			*										*			٠	*				SL	icatio	Identi	Speedster Part Identifications
.V-15							*								*	+	*						able .	Speedometer Cable
Spare the Mount Body SupportV-4						*													:	1	bo	ine Ai	TUL BOO	Le IVIOL